


Gas Conversion Kits	
RSC199i	103000076
RSC199e	103000077
RSC160i	103000080
RSC160e	103000081



ITEM	DESCRIPTION	PART NUMBER	RSC199i	RSC199e	RSC160i	RSC160e	ITEM	DESCRIPTION	PART NUMBER	RSC199i	RSC199e	RSC160i	RSC160e	ITEM	DESCRIPTION	PART NUMBER	RSC199i	RSC199e	RSC160i	RSC160e
003	Lower Wall Mount Bracket	109000281	1	2	1	2	138	Thermistor	105000262	1	1	1	1	431	Heat Exchanger Pipe Connection	107000274	1	1	1	1
004	Upper Wall Mount Bracket	109000594	1	1	1	1	139	Clip	105000090	1	1	1	1	432	O-Ring	107000325	3	3	3	3
007	Connection Reinforcement Plate	109000595	1	1	1	1	140	Secondary Heat Exchanger	107000266	1	1	1	1	433	Pipe Bracket	109000637	1	1	1	1
008	Rubber Bushing	109000634	1	1	1	1	141	Secondary Heat Exchanger Bracket	109000615	1	1	1	1	434	Retention Clip	109000496	2	2	2	2
010	Residential Screw and Washer	106000645	4	4	4	4	142	Secondary Heat Exchanger Gasket	109000616	1	1	1	1	435	Hot Water Connection Fitting	107000275	1	1	1	1
011	Commercial Screw and Washer-Black	109000596	8	8	8	8	145	Condensate Trap	107000267	1	1	1	1	436	Connection Pipe Assembly-Small	107000276				
012	Combustion Chamber Support Plate	109000597	2	2	2	2	147	Condensate Drain tube	107000268	1	1	1	1	442	Clip	109000638	1	1	1	1
013	Truss Screw	109000598	19	19	19	19	150	Electrode/Flame Rod Assembly	105000232	1	1	1	1	443	Retention Clip	U211-322X01	1	1	1	1
014	Pump Circuit Bracket	109002000	1	1	1	1	151	Electrode	105000233	1	1	1	1	446	Hot Water Supply Connection Pipe	107002001	1	1	1	1
015	Igniter Bracket	109000599	1	1	1	1	152	Flame Rod	105000234	1	1	1	1	452	Clip	109000639	1	1	1	1
016	Igniter Assembly	105000230	1	1	1	1	153	Electrode Packing	109000617	1	1	1	1	455	Bypass Tube (set) - P	107000297	1	1	1	1
017	Grounding Screw	107002000	1	1	1	1	154	Electrode Plate	109000618	1	1	1	1	460	Hot Water Servo Valve Assembly	107000279	1	1	1	1
018	Controller Bracket FF	109000600	1				155	Electrode Heater Bracket	109000619	1	1	1	1	462	Hot Water Supply Connection	107002002	1	1	1	1
019	Controller	105000260	1	1	1	1	156	Electrode Sleeve	109000620	1	1	1	1	465	Thermistor	107000320	1	1	1	1
020	Thermistor Sensor	105000261	1	1	1	1	200	Exhaust Duct Assembly FF	108000082	1				471	O-Ring	107000326	4	4	4	4
021	TH Packing	109000490	1	1	1	1	202	O-Ring	108000018	2				472	Clip	109000278	2	2	2	2
033	Rubber Bush	109000802		1			203	Exhaust Duct Packing	109000621	1				475	Pressure Relief Valve Connection	107000282	1	1	1	1
034	Controller Bracket W	109000603		1			204	Thermistor	105000235	1				479	Relief Pipe Assembly	107002003	1	1	1	1
040	Front Cover Panel Assembly FF	109000604	1		1		205	O-Ring	107000323	4	4	4	4	490	Clip	109002001	3	3	3	3
042	Front Cover Panel Assembly W	109000606		1		1	206	Exhaust Packing	109000646	1	1	1	1	491	Pump Connection	107002004	2	2	2	2
044	Screw Cover	109000230	2	2	2	2	207	Thermistor Screw	109000622	1	1	1	1	501	Circulation Pump Assembly	107002005	1	1	1	1
045	Front Panel Packing-Top	109000120	2	2	2	2	210	Flue Connection Assembly	108000083	1				503	Anti-vibration Stand	109002003	1	1	1	1
046	Front Panel Packing-Side FF	109000608	2		2		212	Exhaust Pipe Connection Port - 2"	108000084	1				504	Pump Fixing Stand	109002004	1	1	1	1
047	Front Panel Packing-Side W	109000121		2		2	213	Exhaust Gasket - 2 inch	109000623	1		1		507	Water Supply Connection w/Check Valve	107000305	1	1	1	1
100	Burner Assembly-Large	106000113	1	1			215	Air supply pipe seal ring	108000017	1		1		508	Circular Joint Connection w/Check Valve	107002006	1	1	1	1
101	Burner Gasket-Large	109000609	1	1			220	Air supply box	108000085	1		1		509	Check valve	107000134	2	2	2	2
102	Burner Plate Assembly-Large	106000114	1	1			221	Air supply filter	108000086	1		1		512	Drain plug	107000533	3	3	3	3
103	Combustion Check Valve Assembly	107000262	1	1	1	1	222	Air Supply Connection	108000087	1		1		513	O-Ring	109000182	3	3	3	3
105	Burner Assembly-Small	106000115			1	1	223	Air Supply Gasket - 2 inch	109000624	1		1		521	Pump Outlet Connection Pipe Assembly	107002007	1	1	1	1
106	Burner Gasket-Small	109000610			1	1	230	Exhaust Duct Assembly W	108000088		1		1	600	Pump Circuit Assembly	105002000	1	1	1	1
107	Burner Plate Assembly-Small	106000116			1	1	233	Front Exhaust Seal W	108000094		1		1	601	Pump Circuit	105002001	1	1	1	1
110	Combustion Fan Assembly	108000081	1	1	1	1	234	Thermistor	105000263	1		1		603	Pump Circuit Plate	109002005	1	1	1	1
111	Fan Mounting Packing	109000611	1	1	1	1	401	Water Supply Filter Plug Assembly	107000317	1	1	1	1	701	PCB Electrical Cover	109000626	1	1	1	1
112	O-Ring	109000612	1	1	1	1	403	Water Flow Sensor Assembly	107000269	1	1	1	1	703	PC Board Assembly	105002002	1	1	1	1
113	Hexagon Head Screw	109000803	5	5	5	5	404	Clip	109000636	3	3	3	3	704	PCB EC Cover	109002006	1	1	1	1
114	Gas Valve Assembly With Orifice	106000117	1	1	1	1	405	O-Ring	107000324	9	9	9	9	710	Power Cord Assembly FF	105000238	1			
115	O-Ring	109000252	2	2	2	2	406	Bypass Servo Assembly	107000270	1	1	1	1	711	Power Cord Assembly W	105000239		1		1
116	Gas Connection Pipe	106000118	1	1	1	1	407	Cover	107000093	2	2	2	2	712	Sensor Harness	105000240	1	1	1	1
117	Gas Tube Bracket	109000635	1	1	1	1	408	Inlet Water Thermistor	107000318	1	1	1	1	714	Pump Sensor Harness	105002003	1	1	1	1
118	Inlet Gas Supply Connection	106000119	1	1	1	1	409	Flow Turbine Assembly	107000319	1	1	1	1	715	Pump Harness-2	105002004	1	1	1	1
119	Inlet Gas Test Port Screw	106000138	2	2	2	2	411	O-Ring	M10B-2-14	8	8	8	8	717	Ceramic Valve heater FF	109000654	1			
120	O-Ring	M10B-13-4	2	2	2	2	412	Retention Clip	AH69-310	3	3	3	3	719	Igniter Ground Harness	105000243	1	1	1	1
121	Noise Filter	106000120	1	1	1	1	413	Clip	109000244	3	3	3	3	720	Freeze Protection Heater	105002005	1			
130	Heat Exchanger Assembly-Large	107000263	1	1			414	Plug Band	109000018	1	1	1	1	723	HEX Freeze Protection Heater Assembly	105000246	1	1	1	1
131	Heat Exchanger Assembly-Small	107000264			1	1	415	3/4 Water Supply Connection Port B	107000400	1	1	1	1	724	Sec. HEX Freeze Protection Heater Assy	105000247	1	1	1	1
133	Heater Bracket	109000613	2	2	2	2	417	Water Supply Connection Pipe (pair)	107002000	1	1	1	1	730	Heater Clip A	AU124-618X01	1	1	1	1
135	Over Heat Sensor (OHS)	105000231	1	1	1	1														