




Hydronic Omnipanel Specifications



Mounting Bracket Locations



Actual Width W	16 in	20 in	24 in	30 in	36 in
Pipe CL to CL	14 in	18 in	22 in	28 in	34 in

Model	H	A	B	Z
TW9	26.1 in	2.8 in	14.6 in	2.0 in
TW12	34.8 in	2.8 in	23.4 in	2.0 in
TW15	43.6 in	2.8 in	32.1 in	2.0 in
TW18	52.3 in	2.8 in	40.8 in	2.0 in
TW21	61.1 in	2.8 in	49.5 in	2.0 in

H = Height Dimension

A = A Connection CL to Wall Dimension

B = Bracket to Bracket Dimension

Z = Z Connection Wall to Panel Dimension

Runtal North America, Inc.

187 Neck Road

PO Box 8278

Ward Hill, MA 01835

1-800-526-2621

In Canada: 1-888-829-4901

Fax 1-978-372-7140

<http://www.runtalnorthamerica.com>

info@runtalnorthamerica.com