





A Type Connections  A Type Supply Left  A Type Supply Right	B Type Connections  B Type Supply Left  B Type Supply Right
A & B Combination Connections  A Type Supply Left B Type Return Right  A Type Supply Right B Type Return Left	B & A Combination Connections  B Type Supply Left A Type Return Right  B Type Supply Right A Type Return Left
 AB Combination Connections allow for all types of A & B piping Flush Plugs are included for closing off the unused tapings (AB connections are NOT Available on HX and R1000 Radiators)	
C Type Connections  C Type Supply Left  C Type Supply Right	D Type Connections  D Type Supply Left  D Type Supply Right
E Type Connections  E Type Supply Left  E Type Supply Right	Z Type Connections  Z Type Supply Left  Z Type Supply Right