

SW2, SW2-US Auxiliary Switch Kit for Smart Act Damper Actuators MNXX20, MNXX34, MSXX05, MSXX10, MSXX20

- D Montageanweisung
- DK Installasjonsinstruktus
- ES Instrucciones de Montaje
- F Instructions d'Installation
- I Istruzioni di Montaggio
- N Installations Instruktioner
- NL Installatievoorschrift
- S Installation Instruktioner
- FI Asennusohje

INSTALLATION INSTRUCTIONS

<p>1</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm)</p> <p>100 Vac, 5 (3) A</p> <p>2-3/8 - 3-1/8 in. (60 - 80 mm)</p> <p>3/16 in. (5 mm)</p> <p>M25331</p>	<p>2</p> <p>M25332</p>	<p>3 (MSXX05, MSXX10, MSXX20)</p> <p>M25333</p>
<p>4</p> <p>Ø = 4 ... 000 AWG (5 ... 10 mm)</p> <p>100 Vac, 5 (3) A</p> <p>2-3/8 - 3-1/8 in. (60 - 80 mm)</p> <p>3/16 in. (5 mm)</p> <p>M25331</p>	<p>5</p> <p>24 V + 24 V ✓</p> <p>M25335</p>	<p>6</p> <p>M25336</p>
<p>7</p> <p>6 Nm</p> <p>20 mm</p> <p>M25337</p>	<p>8</p> <p>AS1</p> <p>AS2</p> <p>S3, S1, S2</p> <p>S6, S4, S5</p> <p>C, D</p> <p>0, 90, 45, 90, 0</p> <p>M25338</p>	<p>9 Setting AS1, AS2</p> <p>10-15</p> <p>M25339</p>



<p>10 Setting AS1 (e.g. to 30°)</p> <p>M25340</p>	<p>11</p> <p>M25341</p>	<p>12 Result (10 + 11)</p> <p>M25342</p>																																								
<p>13 Setting AS2 (e.g. to 75°)</p> <p>M25343</p>	<p>14</p> <p>M25344</p>	<p>15 Result (13 +14)</p> <p>M25345</p>																																								
<p>16</p> <p>M25346</p>	<table border="0"> <tr> <td>E</td> <td>result</td> <td>setting</td> <td>e. g. to</td> </tr> <tr> <td>D</td> <td>ergebnis</td> <td>eistellen</td> <td>z. b. auf</td> </tr> <tr> <td>DK</td> <td>resultat</td> <td>justering</td> <td>f. eks</td> </tr> <tr> <td>ES</td> <td>resultado</td> <td>ajuste</td> <td>e. g. en</td> </tr> <tr> <td>F</td> <td>résultat</td> <td>ajustment</td> <td>p. a. au</td> </tr> <tr> <td>I</td> <td>risultato</td> <td>aggiustaggio</td> <td>p. e. in</td> </tr> <tr> <td>N</td> <td>resultat</td> <td>justering</td> <td>f. eks</td> </tr> <tr> <td>NL</td> <td>resultat</td> <td>instellen</td> <td>b. v.</td> </tr> <tr> <td>S</td> <td>resultat</td> <td>inställning</td> <td>ex.</td> </tr> <tr> <td>FI</td> <td>tulos</td> <td>asetta</td> <td>esim</td> </tr> </table>		E	result	setting	e. g. to	D	ergebnis	eistellen	z. b. auf	DK	resultat	justering	f. eks	ES	resultado	ajuste	e. g. en	F	résultat	ajustment	p. a. au	I	risultato	aggiustaggio	p. e. in	N	resultat	justering	f. eks	NL	resultat	instellen	b. v.	S	resultat	inställning	ex.	FI	tulos	asetta	esim
E	result	setting	e. g. to																																							
D	ergebnis	eistellen	z. b. auf																																							
DK	resultat	justering	f. eks																																							
ES	resultado	ajuste	e. g. en																																							
F	résultat	ajustment	p. a. au																																							
I	risultato	aggiustaggio	p. e. in																																							
N	resultat	justering	f. eks																																							
NL	resultat	instellen	b. v.																																							
S	resultat	inställning	ex.																																							
FI	tulos	asetta	esim																																							

Automation and Control Solutions

Honeywell International Inc.
 1985 Douglas Drive North
 Golden Valley, MN 55422
 customer.honeywell.com

Honeywell Limited-Honeywell Limitée
 35 Dynamic Drive
 Toronto, Ontario M1V 4Z9

