

BOILER REPLACEMENT PARTS



Trade Prices & Ordering Guide

January 19, 2010

When ordering replacement parts, specify the boiler model number, serial number and fuel by name (natural gas, LP gas or oil).

Table of Contents

Sentinel	3-4
Sentry	4-5
Victory V-Series	6-7
Victory VH-Series	7-8
Victory VHS-Series	8-9
Victory VSPH-Series	10
Bobcat 120 Series	11
Bobcat 200 Series	12
Lynx Series	13
Galaxy Series	14-15
Prodigy KC 45/90	15
Prodigy KC 50/100	15-16
Prodigy KCS 50/100	15-16
Concept	16-17
Liberty L-Series	17-18
Liberty LD-Series / Intrepid TR Series	18-19
XL- 2000	19

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Aquastat, (Honeywell L8148E1273)	410-538-000	141.00	 Roll out switch, switch only, SE70	411-883-000	10.00
 Burner tube	440-539-000	10.14	 Roll out switch, switch only, SE105	460-546-000	10.00
 Burner tube with pilot bracket	440-540-000	11.93	 Roll out switch, switch only, SE140	460-547-000	10.00
 Gas valve, natural, (Honeywell VR8200A2421) standing pilot, SE70 - SE140	460-510-000	126.00	 Roll out switch, switch only, SE175 & SE210	460-548-000	10.00
 (Honeywell VR8200A2421) Gas valve, natural, standing pilot, SE175 - SE245	460-550-000	127.00	 Roll out switch, switch only, SE245	460-549-000	10.00
 (Honeywell VR8300A2130) Gas valve, propane, standing pilot all models	460-511-000	110.00	 Relief valve, water, 30 psi	400-103-000	15.45
 (Honeywell VR8200A2439) Pilot assembly, natural, standing	411-805-000	7.28	 Tridicator (pressure- temperature gauge)	910-373-061	29.16
 (Honeywell Q350A1321) Pilot assembly, propane, standing	412-417-000	7.60	INTERMITTENT IGNITION ONLY		
			 Gas valve, IID natural, (Honeywell VR8204A2266) SE70 - SE175	440-534-000	111.00
 (Honeywell Q314A3679) Pilot tube	410-530-000	2.33	INTERMITTENT IGNITION ONLY		
			 (Honeywell VR8304M2105) Gas valve, IID natural, SE210 - SE245	460-552-000	120.00
 Thermocouple (Honeywell Q309A2150)	410-539-000	10.93	INTERMITTENT IGNITION ONLY		
			 (Honeywell VR8204A2258) Gas valve, IID propane, all size boilers	440-535-000	107.00
 Blocked vent safety switch assembly	412-643-000	11.37	INTERMITTENT IGNITION ONLY		
			 IID Ignition control, natural	412-101-000	103.00

SENTINEL

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
INTERMITTENT IGNITION ONLY			INTERMITTENT IGNITION ONLY		
 IID Ignition control, propane	412-808-000	103.00	 IID pilot, propane (Honeywell Q345A/.012-BBR12)	411-857-000	27.84
INTERMITTENT IGNITION ONLY			INTERMITTENT IGNITION ONLY		
 IID pilot, natural (Honeywell Q345A/.018-BCR18)	411-612-000	25.25	 IID ignition wire	460-531-000	19.61




SENTRY

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Aquastat, (Honeywell L8148E1273)	410-538-000	141.00	 Pilot tube	410-530-000	2.33
 Burner	440-539-000	10.14	 Thermocouple	410-539-000	10.93
 Burner with pilot bracket	440-540-000	11.93	 Blocked vent safety switch, S34 - S150	460-500-000	9.07
 Gas valve, natural, standing pilot, S34 - SX150 (Honeywell VR8200A2421)	460-510-000	126.00	 Blocked vent safety switch assembly, all SX models	412-643-000	11.37
 Gas valve, natural, standing pilot, SX180 - SX210 (Honeywell VR8300A2130)	460-550-000	127.00	 Roll out switch, switch only, S34 only	411-883-000	10.00
 Gas valve, propane, standing pilot, all propane boilers (Honeywell VR8200A2439)	460-511-000	110.00	 Roll out switch, switch only, S60 - S90	440-721-000	10.00
 Pilot assembly, natural, standing (Honeywell Q350A1321)	411-805-000	7.28	 Roll out switch, switch only, S120 - S150	460-547-000	10.00
 Pilot assembly, propane, standing (Honeywell Q314A3679)	412-417-000	7.76	 Roll out switch, switch only, SX150 - SX210	460-548-000	10.00

SENTRY

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
	Relief valve, water, 30 psi 400-103-000	15.45		INTERMTTENT IGNITION ONLY IID Ignition cable, S150, SX150 - SX210 460-531-000	19.61
	Tridicator (temperature-pressure gauge) 910-373-061	29.16		INTERMTTENT IGNITION ONLY .IID Ignition control, natural 412-101-000	103.00
	INTERMTTENT IGNITION ONLY Gas valve, natural IID, all except SX210 (Honeywell VR8204A2266) 440-534-000	111.00		INTERMTTENT IGNITION ONLY IID Ignition control, propane 412-808-000	103.00
	INTERMTTENT IGNITION ONLY Gas valve, natural IID, SX210 only (Honeywell VR8304M2105) 460-552-000	120.00		INTERMTTENT IGNITION ONLY IID Pilot, natural (Honeywell Q345A/.018-BCR18) 411-612-000	25.25
	INTERMTTENT IGNITION ONLY Gas valve, propane IID, all propane boilers (Honeywell VR8204A2258) 440-535-000	107.00		INTERMTTENT IGNITION ONLY IID Pilot, propane (Honeywell Q345A/.012-BBR12) 411-857-000	27.84
	INTERMTTENT IGNITION ONLY IID Ignition cable S34 - S120 411-874-000	10.35			




VICTORY V

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Air pressure switch, V-33, sea level to 5000'	440-517-000	34.02	 Ignition cable V33-V120	411-874-000	10.35
 Air pressure switch, V-60, sea level to 5000'	440-511-000	34.02	 Ignition cable V150-V180	440-153-000	27.84
 Air pressure switch, V-90, sea level to 5000'	440-518-000	34.02	 IID ignition control, natural	412-101-000	103.00
 Air pressure switch, V-120, sea level to 5000'	440-513-000	34.02	 IID ignition control, propane	412-808-000	103.00
 Air pressure switch, V-150, sea level to 5000' (also used on V120, OVER 5000')	453-056-000	22.73	 Inducer assembly (complete) V-33	440-634-000	233.00
 Air pressure switch, V-180, sea level to 5000'	440-516-000	34.02	 Inducer assembly (complete) V-60	440-635-000	233.00
 Aquastat, (Honeywell L8148E1273)	410-538-000	141.00	 Inducer assembly (complete) V-90	440-636-000	233.00
 Burner	440-539-000	10.14	 Inducer assembly (complete) V-120	440-637-000	233.00
 Burner with pilot bracket	440-540-000	11.93	 Inducer assembly (complete) V-150	440-638-000	233.00
 Gas valve, IID natural (Honeywell VR8204A2266)	440-534-000	111.00	 Inducer assembly (complete) V-180	440-639-000	233.00
 Gas valve, IID propane (Honeywell VR8204A2258)	440-535-000	107.00	 Inducer relay (WR134-20102-101)	440-543-000	14.23




VICTORY V

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Pilot assembly, natural (Honeywell Q345A/.018-BCR18)	411-612-000	25.25	 Relief valve, water, 30 psi	400-103-000	15.45
 Pilot assembly, propane (Honeywell Q345A/.012-BBR12)	411-857-000	27.84	 Rollout switch, switch only	440-583-000	10.00
 Pilot tube	410-530-000	2.33	 Tridicator (pressure-temperature gauge)	910-373-061	42.00

VICTORY VH

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Burner	440-539-000	10.14	 Pilot tube	410-530-000	2.33
 Burner with pilot bracket	440-540-000	11.93	 Relief valve, water, 30 psi	400-103-000	15.45
 Air pressure switch, all models	440-744-000	24.40	 Tridicator (temperature-pressure gauge)	910-373-061	29.16
 Ignitor assembly	440-819-000	44.11	 Blower	440-745-000	140.00
 Gas valve, natural (Honeywell SV9540M2260)	440-741-000	NOT AVAILABLE	 Inducer assembly complete VH-30	440-762-000	233.00
 Gas valve, propane (Honeywell SV9540M2278)	440-742-000	NOT AVAILABLE	 Inducer assembly complete VH-60	440-763-000	233.00
 Transformer	660-528-000	18.90	 Inducer assembly complete VH-90	440-764-000	233.00








VICTORY VH

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Inducer assembly complete VH-120	440-765-000	233.00	 Roll out switch only VH-150	440-721-000	10.00
 Inducer assembly complete VH-150	440-766-000	233.00	 Roll out switch only VH-180	460-547-000	10.00
 Inducer assembly complete VH-180	440-767-000	233.00	 VH-VHS conversion kit natural gas to convert VH model to VHS model	440-829-000	386.00
 Roll out switch only VH30 - VH60	411-883-000	10.00	 VH-VHS conversion kit propane to convert VH model to VHS model	440-833-000	395.00
 Roll out switch only VH90 - VH120	440-720-000	10.00			






VICTORY VHS

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Burner	440-539-000	10.14	 Gas valve, natural (Honeywell VR8204A2266)	440-534-000	111.00
 Burner with pilot bracket	440-540-000	11.93	 Gas valve, propane (Honeywell VR8204A2258)	440-535-000	107.00
 Air pressure switch, all models	440-744-000	24.40	 Pilot tube	410-530-000	2.33
 Pilot assembly, natural (Honeywell Q345A1008)	411-612-000	25.25	 Relief valve, water, 30 psi	400-103-000	15.45
 Pilot assembly, propane (Honeywell Q345A1008)	411-857-000	27.84	 Aquastat (Honeywell L8148E1273)	410-538-000	141.00

VICTORY VHS

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Ignition Control (Natural)	412-101-000	103.00	 Inducer assembly complete VHS-90	440-764-000	233.00
 Ignition Control (Propane)	412-808-000	103.00	 Inducer assembly complete VHS-120	440-765-000	233.00
 Ignition Cable	440-153-000	27.84	 Inducer assembly complete VHS-150	440-766-000	233.00
 Inducer Relay (WR134-20102-101)	440-543-000	14.23	 Inducer assembly complete VHS-180	440-767-000	233.00
 Tridicator (temperature-pressure gauge)	910-373-061	29.16	 Roll out switch only VHS-30 – VHS-60	411-883-000	10.00
 Blower	440-745-000	140.00	 Roll out switch only VHS-90 – VHS-120	440-720-000	10.00
 Inducer assembly complete VHS-30	440-762-000	233.00	 Roll out switch only VHS-150	440-721-000	10.00
 Inducer assembly complete VHS-60	440-763-000	233.00	 Roll out switch only VHS-180	460-547-000	10.00

VICTORY VSPH

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Burner	440-539-000	10.14	 Main Control (UT 1107-12)	453-037-000	160.00
 Burner with pilot bracket	440-540-000	11.93	 Ignition Cable	440-153-000	27.84
 Air pressure switch: VSPH 60 + 90 VSPH 120 VSPH 150 +180	453-053-000 453-054-000 453-055-000	24.40 24.40 24.40	 Tridicator (temperature-pressure gauge)	910-373-061	29.16
 Pilot assembly, natural (Honeywell Q345A1008)	411-612-000	25.25	 Blower	453-043-000	152.00
 Pilot assembly, propane (Honeywell Q345A1008)	411-857-000	27.84	 Inducer assembly complete VSPH-60	451-117-000	233.00
 Gas valve, natural (Honeywell VR8204A2266)	440-534-000	111.00	 Inducer assembly complete VSPH-90	451-118-000	233.00
 Gas valve, propane (Honeywell VR8204A2258)	440-535-000	107.00	 Inducer assembly complete VSPH-120	451-119-000	233.00
 Pilot tube	410-530-000	2.33	 Inducer assembly complete VSPH-150	451-120-000	233.00
 Relief valve, water, 30 psi	400-103-000	15.45	 Inducer assembly complete VSPH-180	451-121-000	233.00
 Aquastat (Honeywell L4080B1253)	410-699-000	57.75	 Roll out switch only (All models)	440-721-000	10.00

BOBCAT B-120

DESCRIPTION PART # PRICE			DESCRIPTION PART # PRICE		
Photo not available	Propane Conversion Kit	860-905-000 12.60	Photo not available	Control Board Propane	842-609-000 294.00
Photo not available	Gas Valve	863-208-000 117.00	Photo not available	LED Display Assembly	832-606-000 78.75
Photo not available	Blower	863-215-000 105.00	Photo not available	24v Transformer	660-528-000 18.90
Photo not available	Venturi	863-209-000 36.75	Photo not available	Taco 0011 Circulator	863-804-000 255.00
Photo not available	Spark Ignitor	863-408-010 31.21	Photo not available	Pressure Gauge	863-611-000 18.90
Photo not available	Water Sensor	863-406-000 18.90	Photo not available	Spark Cable	862-101-100 9.00
Photo not available	Water High Limit	863-404-000 24.15	Photo not available	Outdoor Sensor	863-805-000 38.50
Photo not available	Flue Sensor	863-501-000 24.15	Photo not available	Gas Valve Cable	862-104-000 15.00
Photo not available	Control Board Natural	842-610-000 294.00	Photo not available		

BOBCAT B-200

DESCRIPTION				PART #	PRICE	DESCRIPTION				PART #	PRICE
	Propane Conversion Kit			860-955-000	12.60		Control Board Propane			862-604-000	294.00
	Gas Valve			863-208-000	117.00		LED Assembly Kit			832-606-000	78.75
	Blower			863-265-000	149.00		24v Transformer			660-528-000	18.90
	Venturi			863-259-000	48.30		Taco 0013 Circulator			863-806-000	326.00
	Spark Ignitor			863-408-010	31.21		Pressure Gauge			863-611-000	18.90
	Water Sensor			863-406-000	18.90		Outdoor Sensor			863-805-000	38.50
	Water High Limit			863-404-000	24.15		Spark Cable			862-101-100	9.00
	Flue Sensor			863-501-000	24.15		Gas Valve Cable			862-104-000	15.00
	Control Board Natural			862-605-000	294.00						

DESCRIPTION PART # PRICE			DESCRIPTION PART # PRICE		
Photo not available	Gas Valve	863-208-000 117.00	Photo not available	Control Board Propane	842-607-000 294.00
Photo not available	Blower	863-215-000 105.00	Photo not available	Transformer	660-528-000 18.90
Photo not available	Venturi	843-209-000 35.70	Photo not available	Taco 0011 Circulator	863-804-000 255.00
Photo not available	Spark Ignitor	843-218-000 31.50	Photo not available	Pressure Gauge	863-611-000 18.90
Photo not available	Water Sensor	842-410-000 15.75	Photo not available	Spark Cable	862-101-100 9.00
Photo not available	Water High Limit	842-411-000 24.15	Photo not available	Outdoor Sensor	863-805-000 38.50
Photo not available	Flue Sensor	842-512-000 22.05	Photo not available	Conversion Kit Propane	840-905-000 12.60
Photo not available	Control Board Natural	842-608-000 294.00	Photo not available	Gas Valve Cable	862-104-000 15.00

GALAXY

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Aquastat (Honeywell L8148E1273) 410-538-000 141.00			 Pilot assembly propane standing All GG to GG300 & All GXH to GXH300 (Honeywell Q314A/.010-BBR10) 411-858-000 7.97		
 Aquastat, boilers with tankless (Honeywell L8124E1065) 410-537-000 210.00			 Thermocouple GG75H-GG300H & All GXH (Honeywell Q309A2150) 410-539-000 10.93		
 Burner 410-508-000 14.62			 Relief valve, all water boilers, 30 psi 400-103-000 15.45		
 Burner with pilot bracket 410-479-000 17.60			 Relief valve, all steam boilers, 15 psi 400-107-000 38.82		
 Gas valve, 24v natural, GG75H-GG150H, GXH105-GXH125 standing (Honeywell VR8200A2215) 411-862-000 107.00			 Blocked vent safety switch assembly All GG & GX/GXH EXCEPT GXH105 & GG399H 412-641-000 22.14		
 Gas valve, 24v natural, GG175H-GG225H, GXH150-GXH190 standing (Honeywell VR8300A3153) 411-924-000 129.00			 Blocked vent safety switch assembly GXH105 and GG399H 412-642-000 17.70		
 Gas valve, 24v natural, GG250H-GG300, GXH210-GXH300 standing (Honeywell VR8300A4045) 411-926-000 129.00			 Roll out switch, (switch only) All GG and GX/GXH 411-883-000 10.00		
 Gas valve, 24v propane GG75H-GG300, GXH105-GXH300 standing (Honeywell VR8300A3559) 411-925-000 133.00			 Tridicator (pressure temperature gauge) 910-373-061 29.16		
 Pilot tube 410-530-000 2.33			INTERMITTENT IGNITION ONLY  Gas valve, Natural IID GG75-GG175 and GXH105 - GXH190 (Honeywell VR8204A2126) 411-864-000 106.00		
 Pilot fitting 411-768-000 2.90			INTERMITTENT IGNITION ONLY  Gas valve, Natural IID GG200-GG325 and GXH210 - GXH300H (Honeywell VR8304M3103) 411-927-000 107.00		
 Pilot assembly, natural standing GG75H-GG300, GXH105-GXH300H (Honeywell Q350A1321) 411-805-000 7.28			INTERMITTENT IGNITION ONLY  Gas valve, Natural IID GG350H-GG399H (Honeywell VR8304M4002) 411-929-000 129.00		

GALAXY

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
INTERMITTENT IGNITION ONLY			INTERMITTENT IGNITION ONLY		
 Gas valve, Propane IID, all propane boilers (Honeywell VR8304M3186)	411-928-000	170.00	 IID Pilot, natural (Honeywell Q345/.018-BCR18)	411-612-000	25.25
INTERMITTENT IGNITION ONLY			INTERMITTENT IGNITION ONLY		
 IID Ignition control, natural	412-101-000	103.00	 IID Pilot, propane (Honeywell Q345A/.012-BBR12)	411-857-000	27.84
INTERMITTENT IGNITION ONLY			INTERMITTENT IGNITION ONLY		
 IID Ignition control, propane	412-808-000	103.00	 IID Ignition wire	411-874-000	10.35

PRODIGY KC 45/90

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Combustion blower	651-703-000	185.00	 Hot surface ignitor KC45	650-595-000	31.84
 Flame detector KC-90	650-516-000	52.32	 Hot surface ignitor KC90	650-519-000	31.84
 Flame detector KC-45	650-615-000	22.32	 Relief valve	650-550-000	14.69
 LED Board	650-559-000	59.06	 Gas valve, both KC45 & KC90 (Robert Shaw RS7200 DERN)	660-520-000	135.00
NOT AVAILABLE (see note *)					
 Main Control Board	650-558-000	373.00			

* Note: The two stage electronic control board is no longer being manufactured. The control board retrofit kit part number, 651764, will be used to convert the boiler to a single input, using a United Technology control board. For price and conversion instructions, consult factory.

PRODIGY KC 50/100

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Combustion blower	651-703-000	185.00	 Flame detector KC-50 & 100	660-501-000	31.95


PRODIGY KC 50/100

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
NOT AVAILABLE (see note †)					
 Main Control Board	651-308-000	373.00	 Relief valve	650-550-000	14.69
† Note: The two stage electronic control board is no longer being manufactured. The control board retrofit kit part number, 651772, will be used to convert the boiler to a single input, using a United Technology control board. For price and conversion instructions, consult factory.					
 Hot surface ignitor KC50/100	660-720-000	40.20	 Gas valve, both KC50 & 100 (Robert Shaw RS7200)	660-520-000	135.00


PRODIGY KCS 50/100

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Combustion blower	660-527-000	181.00	 Hot surface ignitor KCS 50/100	660-720-000	40.20
 Flame detector KCS 50 & 100	660-501-000	31.95	 Relief valve	650-550-000	14.69
 Main Control Board	660-589-000	202.00	 Gas valve, both KC50 & 100 (Robert Shaw RS7200)	660-520-000	135.00

CONCEPT

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Combustion blower	660-527-000	181.00	 Main control board	665-186--000	207.00
 Flame detector	660-501-000	31.95	 Relief valve, water, 30 psi	650-550-000	14.69
see note *)					
 Hot surface ignitor (old style for serial numbers BELOW 3000 ‡)	660-502-000	40.14	 Tridicator (pressure temperature gauge)	910-373-061	29.16
‡ Note: HSI for boilers with serial nos. between 3000 and 5000, part # 660593 is no longer available. Use kit # 665040 for initial replacement. Use HSI # 660-720-000 for subsequent replacements.					
 Hot surface ignitor (Boiler with serial number over 3000)	660-720-000	40.20	 Air pressure switch	660-592-000	25.65

CONCEPT

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Gas valve (Robert Shaw RS7200)	660-520-000	135.00	 Transformer	660-528-000	18.90

LIBERTY L

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Burner Mounting plate insulation	430-018-000	40.12	 Burner ignition transformer (Beckett burner-new style)	430-671-000	92.78
 Target wall	430-029-000	38.78	 Burner ignition transformer (Carlin burner)	401-323-000	93.50
 Sealant for mounting plate (50" needed)	430-136-000	.05/ft	 Burner motor (3450 rpm) (Beckett PSC)	430-673-000	240.00
 Sealant for flue collector	430-147-000	.11/ft	 Single stage fuel pump (clean cut)	430-670-000	\$172.00
 Relief valve, water, 30 psi	400-103-000	15.45	 Cad cell	430-417-000	21.25
 Relief valve, steam, 15 psi	400-107-000	38.82	 Gasket for tankless coil, water	430-071-000	4.75
 Primary control (Honeywell R7184B1032)	430-672-000	169.00	 Gasket for tankless coil, steam	430-070-000	11.01
 Aquastat relay (for boilers with tankless) (Honeywell L8124C1102)	400-095-000	205.00	 Gasket for Carlin burner	430-173-000	7.02
 Aquastat relay (for boilers without tankless) (Honeywell L8148A1140)	400-096-000	147.00	 Gasket for Beckett burner	430-172-000	5.31

LIBERTY L

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Pressuretrol control (steam boilers only) (Honeywell PA404A1009) 400-117-000 103.00			 Delayed oil valve (used on Beckett burner only) 430-558-000 85.00		

LIBERTY LD / INTREPID TR

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Burner Door insulation 430-018-000 40.12			 Burner ignition transformer (Carlin burner) 401-323-000 93.50		
 Target wall 430-029-000 38.78			 Burner motor (3450 rpm) Beckett PSC 430-673-000 240.00		
 Sealant for flue collector 430-147-000 .11/ft			 Single stage fuel pump (clean cut) 430-670-000 172.00		
 Relief valve, water, 30 psi 400-103-000 15.45			 Cad cell 430-417-000 21.25		
 Relief valve, steam, 15 psi 400-107-000 38.82			 Gasket for Carlin burner 430-173-000 7.02		
 Primary control (Honeywell R7184B1032) 430-672-000 169.00			 Gasket for Beckett burner 430-172-000 5.31		
 Aquastat relay (for boilers with tankless) (Honeywell L8124C1102) 400-095-000 205.00			 Pressuretrol control (steam boilers only) (Honeywell PA404A1009) 400-117-000 103.00		
 Aquastat relay (for boilers without tankless) (Honeywell L8148A1140) 400-096-000 147.00			 Delayed oil valve (used on Beckett Burner only) 430-558-000 85.00		
 Burner ignition transformer (Beckett burner-new style) 430-671-000 92.78			 Wire harness (boilers equipped with Beckett burner) 482-131-000 27.57		

LIBERTY LD / INTREPID TR

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Wire harness (boilers equipped with Carlin burner)	482-142-000	30.31			

XL-2000

DESCRIPTION	PART #	PRICE	DESCRIPTION	PART #	PRICE
 Burner door insulation	480-014-000	43.01	 Primary control (Honeywell R7184B1032)	430-672-000	169.00
 Target wall	480-012-000	27.24	 Aquastat (Honeywell L8148A1140)	400-096-000	147.00
 Gasket, Beckett burner	430-172-000	5.31	 Wire harness (boilers equipped with Beckett burner)	482-131-000	27.57
 Gasket, Carlin burner	430-173-000	7.02	 Wire harness (boilers equipped with Carlin burner)	482-142-000	30.31
 Tridicator (temperature-pressure gauge)	910-373-061	29.16	 Delayed oil valve (used on Beckett Burner only)	430-558-000	85.00
 Relief valve, water, 30 psi	400-103-000	15.45	 Cad cell	430-417-000	21.25

