

SpeedClean®

Innovative Maintenance Tools.

Mini-Split Cassette Bib® Kit



SPEEDCLEAN®

OPERATING & MAINTENANCE INSTRUCTIONS

U.S. Patents: 6,863,116, 9,259,769

Thank you for purchasing this SpeedClean Mini-Split Cassette Bib® Kit. We appreciate your business and look forward to serving you in the future. As with all SpeedClean products, you can be assured that the finest quality components and workmanship have gone into this unit.

Please take a few minutes to read the following Operating and Maintenance Instructions. Please pay particular attention to the safety instructions and exercise caution when using this product.

Mini-Split Cassette Bib® Kit

Table of Contents

Setup Instructions	2
Use With These Products	3
Important Safety Instructions.....	4
Limited Warranty	4

Mini-Split Cassette Bib® Kit

Setup Instructions

1. Turn off power to the unit being cleaned.
2. Place hooks securely into the ceiling unit.
3. Tension the Mini-Split Cassette Bib so the drain tube opens.
4. Make sure the center of the Mini-Split Cassette Bib is located directly under the ceiling unit to be cleaned.
5. Place the tube of the Mini-Split Cassette Bib into the 5 gallon bucket provided.
6. Make sure that water doesn't puddle in the bib, this may cause the unit to tip and spill.



(SC-CB-STAND) Optional Stand for Mini-Split Cassette Bib®

1. Carrying Bag (Part# CSB-010)
2. Dolly Assembly (Part# CSB-DA)**
3. Support Pole (Part# CSB-POLE 4-8)
4. Hub, Pole to Frame (Part# CSB-013)
5. Bib Frame (Part# CSB-006)



(SC-CB) Mini-Split Cassette Bib® Includes:

1. Plastic "Bib" (Part# CSB-011)
2. 5 Gallon Bucket (Part# BV-5-BUCKET-70M)
3. Plastic Hooks (Part# HWHK-6218)
4. Adjustable Cord (Part# MSB-06)

Prior to cleaning mini-split cassette bib systems, please read all manufacturer's directions for maintenance and apply any cleaners per their specifically supplied directions.



For Use with Optional Cassette Bib Stand:

1. Ensure that the stand with the attached bib will avoid any ceiling obstructions.
2. Open the Dolly and place it on level ground.
3. Slide the Support Pole into the Pole Support that is located on the Dolly.
4. Screw the Hub onto the support pole.
5. Place the 4 frame rods into the slots on the outside corners of the bib as shown.
6. Place the 4 frame rods into the Hub.
7. Position the center of the Cassette Bib under the ceiling unit to be cleaned.
8. Place the tube of the Cassette Bib into the 5 gallon bucket provided.

WARNING: These rods are made of fiberglass and may cause splinters. Wear gloves when handling these rods. When folding the dolly be careful not shear one's fingers.

WARNING: If the water starts to puddle, manually open the drain tube. If too much water starts to puddle, the balance will be off and the stand may tip over.

**CSB-DA Assembly Includes:

2x Cross Bar (Part# CSB-004)
1x Pole Support (Part# CSB-009)
2x Caster Riser (Part# HWN-37Fx2)
6x Caster Washer (Part# HWW-31)
1x ¼-20 Bolt, 3" (Part# HWS-2520-3SH-SS)

4x Caster (Part# 015-13)
2x Caster Bolt (Part# HWS-3775HH)
2x Caster Acorn Nut (Part# 015-15)
1x Thrust Bearing Washer (Part# HWW-2587-06)
1x Nylon Lock Nut (Part# HWN-251)

Mini-Split Cassette Bib® Kit

Use with These Products

CoilJet® from SpeedClean is a portable coil cleaning system. It is battery operated and includes water, coil cleaner and more. 125 PSI, ½ GPM

Available Accessories:

24" Flexible Wand (Part# 8945-0-DEG-FLEX)



WARNING! READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE USING. KEEP THIS MANUAL WITH THE UNIT AT ALL TIMES.

- Do not operate without eye protection or other necessary protective gear. Consult MSDS on all products used with this machine.
- Consult SpeedClean or chemical manufacturer about mixing or using unspecified chemicals with this unit.
- Minimum & maximum working temperature conditions; 350F – 1200F (20C – 480C)
- Only move an empty bib and watch obstructions on ceiling.
- Keep work area clean and well lit.
- Service must be performed by qualified personnel.
- Use only SpeedClean specified replacement parts.
- Do not use unit with combustible fluids or where combustible fluids or fumes may be present.
- Be extra careful when not on level, secure ground.
- Do not use unit with children or visitors in the immediate area.
- Keep operation area clear of all persons.
- Do not overreach or stand on unstable support. Keep good footing and balance at all times.
- Follow maintenance instructions in manual.
- Stay alert — watch what you are doing.
- Disconnect power from unit being cleaned.
- Make sure the assembly is secure and the adjustable cord is tight. There should be no slack in the adjustable cord.
- Make sure the water is draining into the 5 gallon bucket properly; any kinks in the bib hose should be addressed.
- While cleaning keep an eye on the water level in the 5 gallon bucket so that it does not get too high and overflow.
- Dry and store Mini-Split Cassette Bib® in bucket.

SpeedClean warrants that this item is free from defects in material and workmanship. SpeedClean, under this warranty, will repair or replace any parts that prove, upon examination, to be defective. This warranty is valid for 30 days from date of purchase by original purchaser. This warranty excludes unusual wear, abuse, unreasonable use, or damage resulting from an accident. For warranty information contact SpeedClean directly, not the place of purchase. To obtain warranty service, a proof of purchase is required. Contact SpeedClean Customer Service at (800)700-3540.



SPEEDCLEAN®

PO Box 110301
Stamford, CT 06911-0301
(888) 700-3540
www.speedclean.com

SpeedClean is a registered trademark of Crossford International SpeedClean reserves the right to improve products; contact the factory for the latest configuration and uses.