

Product information presented here reflects conditions at time of publication. Consult factory regarding discrepancies or inconsistencies.



PUMP COMPANY

Zoeller Family of Water Solutions™

MAIL TO: P.O. BOX 16347 • Louisville, KY 40256-0347
SHIP TO: 3649 Cane Run Road • Louisville, KY 40211-1961
(502) 778-2731 • 1 (800) 928-PUMP • FAX (502) 774-3624

SECTION: 6.10.335

FM1427

0111

Supersedes

0507

visit our web site:
www.zoeller.com

REPLACEMENT PARTS LIST FOR MODELS:


N270 NONAUTOMATIC 115V
E270 NONAUTOMATIC 230V
N4270 NONAUTOMATIC 115V
E4270 NONAUTOMATIC 230V

Consult factory for all other models

TO ORDER REPLACEMENT PARTS:

PLEASE FURNISH THE FOLLOWING INFORMATION:

- Model Number.
- Part Number of Pump.
- Part Number and Description of part.



WIRING DIAGRAM FOR MODELS
"N270" All Revisions; "E270" All Revisions;
"N4270" All Revisions; "E4270" All Revisions
6/95 thru Current

REPLACEMENT PARTS LIST FOR SINGLE SEAL MODELS “N270” and “E270” .

See back page for illustration.

		MODELS:		N270-A	N270-B	N270-C	N270-D	N270-E		E270-A	E270-B	E270-C	E270-D	E270-E
REF NO.	DESCRIPTION	QTY	NOTES											
1	HANDLE	1		6/95 thru 5/97	267032	267032	267032	267032		267032	267032	267032	267032	267032
2	CASE ASSEMBLY	1		267051	011549	011549	011549	011549		267051	011549	011549	011549	011549
3	CASE GASKET	1		267007	267007	267007	267007	267007		267007	267007	267007	267007	267007
4	POWER CORD	1	3	010155	011551	018925	011551	011551		011558	003618	019048	003618	003618
5	SEAL ASSEMBLY POWER	1		010154	010154	010154	010154	010154		010154	010154	010154	010154	010154
6	MOTOR HOUSING ASM/SOURCE	1	5	010156	010156	010156	010156	010156		010157	010157	010157	010157	010157
	MOTOR HOUSING ASM/ZT			N/A	N/A	N/A	N/A	150013		N/A	N/A	N/A	N/A	150014
7	ROTOR & BRG ASM/SOURCE	1	5	010994	010994	010994	010994	010994		010994	010994	010994	010994	010994
	ROTOR & BRG ASM/ZT			N/A	N/A	N/A	N/A	150015		N/A	N/A	N/A	N/A	150015
8	BEARING RADIAL	1		009540	009540	009540	009540	009540		009540	009540	009540	009540	009540
9	25 OZ OIL CAN	1		010330	010330	010330	010330	010330		010330	010330	010330	010330	010330
10	SEAL ASSEMBLY	1		011681	011681	011681	011681	011681		011681	011681	011681	011681	011681
11	SQUARE RING SEAL	1		267006	267006	267006	267006	267006		267006	267006	267006	267006	267006
12	BASE	1		010973	010973	010973	010973	010973		010973	010973	010973	010973	010973
13	HANDLE RETAINERS	2		267053	267053	267053	267053	267053		267053	267053	267053	267053	267053
14	TERM INSULATOR	2		001797	N/A	N/A	N/A	N/A		001797	N/A	N/A	N/A	N/A
15	WIRE PACK	1		010159	011548	011548	011548	011548		010159	011548	011548	011548	011548
16	CAPACITOR ASSEMBLY	1	4	010160	011550	011550	011550	011550		010160	011550	011550	011550	011550
17	PUMP HOUSING	1		009519	009519	009519	009519	009519		009519	009519	009519	009519	009519
18	IMPELLER	1		011690	011690	011690	011690	011690		011690	011690	011690	011690	011690
19	SCREW 10-24X3/8	2		001883	001883	001883	001883	001883		001883	001883	001883	001883	001883
20	SCREW 1/4-20X3/	4		001916	001916	001916	001916	001916		001916	001916	001916	001916	001916
21	SCREW 6-32X7/16	1		004644	004644	004644	004644	004644		004644	004644	004644	004644	004644
22	WASHER#6	1		002117	002117	002117	002117	002117		002117	002117	002117	002117	002117
23	GROUND SCREW	1		001877	001877	001877	001877	001877		001877	001877	001877	001877	001877
24	THRU WALL TERMINAL	3		003402	003402	003402	003402	003402		003402	003402	003402	003402	003402
25	O-RING	1		005701	005701	005701	005701	005701		005701	005701	005701	005701	005701
26	SCREW #10-10X1 HHX WASH	10		005326	005326	005326	005326	005326		005326	005326	005326	005326	005326
27	TEST PLUG	2		034090	034090	034090	034090	034090		034090	034090	034090	034090	034090
28	SCREWS	4		012491	012491	012491	012491	012491		012491	012491	012491	012491	012491
▫	REBUILD KIT	1		010173	010173	010173	010173	010173		010173	010173	010173	010173	010173

- Items included in Rebuild Kit. ▫ Not shown in illustration.

NOTES:

- See FM0160 parts price sheet for listing of parts pricing.
- "NA" indicates not applicable.
- If an "X" follows model number or date of manufacture on brass I.D. tag, consult factory for ordering of this part.
- When replacing capacitor assembly on "REV. A" pumps only (Item 16), customer must also replace the case assembly (Item 2).
- When ordering motor housing (Item 6) or rotor and bearing (Item 7), specify either source or ZT motor. ZT stator can be identified by a completely round stator.

REPLACEMENT PARTS LIST FOR DOUBLE SEAL MODELS “N4270” and “E4270”

See back page for illustration.

REF NO.		DESCRIPTION	MODELS:		QTY	NOTES	N4270-A	N4270-B	N4270-C	N4270-D	N4270-E		E4270-A	E4270-B	E4270-C	E4270-D	E4270-E	
1		HANDLE	1				267032	267032	267032	267032	267032	267032	267032	267032	267032	267032	267032	1/09 Current
2		CASE ASSEMBLY	1				267051	011549	011549	011549	011549	011549	267051	011549	011549	011549	011549	011549
3		• CASE GASKET	1				267007	267007	267007	267007	267007	267007	267007	267007	267007	267007	267007	267007
4		POWER CORD	1	3			010155	011551	018925	011551	011551	011551	011558	003618	019048	003618	003618	003618
5		• SEAL ASSEMBLY POWER	1				010154	010154	010154	010154	010154	010154	010154	010154	010154	010154	010154	010154
6		MOTOR HOUSING ASM/SOURCE	1	5			010156	010156	010156	010156	010156	010156	010157	010157	010157	010157	010157	010157
		MOTOR HOUSING ASM/ZT					N/A	N/A	N/A	N/A	150013		N/A	N/A	N/A	150014		
7		ROTOR & BRG ASM/SOURCE	1	5			010996	010996	010996	010996	010996	010996	010996	010996	010996	010996	010996	010996
		ROTOR & BRG ASM/ZT					N/A	N/A	N/A	N/A	150016		N/A	N/A	N/A	150016		
8		• 36.5 OZ OIL CAN	1				010331	010331	010331	010331	010331	010331	010331	010331	010331	010331	010331	010331
9		• 16 OZ OIL CAN	1				010158	010158	010158	010158	010158	010158	010158	010158	010158	010158	010158	010158
10		• SEAL ASSEMBLY	2				011681	011681	011681	011681	011681	011681	011681	011681	011681	011681	011681	011681
11		• SQUARE RING SEAL	2				267006	267006	267006	267006	267006	267006	267006	267006	267006	267006	267006	267006
12		BASE	1				008646	008646	008646	008646	008646	008646	008646	008646	008646	008646	008646	008646
13		HANDLE RETAINERS	2				267053	267053	267053	267053	267053	267053	267053	267053	267053	267053	267053	267053
14		TERM INSULATOR	2				001797	N/A	N/A	N/A	N/A	N/A	001797	N/A	N/A	N/A	N/A	N/A
15		• WIRE PACK	1				010159	011548	011548	011548	011548	011548	010159	011548	011548	011548	011548	011548
16		CAPACITOR ASSEMBLY	1	4			010160	011550	011550	011550	011550	011550	010160	011550	011550	011550	011550	011550
17		• BEARING	1				009540	009540	009540	009540	009540	009540	009540	009540	009540	009540	009540	009540
18		ADAPTER	1				011679	011679	011679	011679	011679	011679	011679	011679	011679	011679	011679	011679
19		PUMP HOUSING	1				010939	010939	010939	010939	010939	010939	010939	010939	010939	010939	010939	010939
20		IMPELLER	1				010690	011690	011690	011690	011690	011690	011690	011690	011690	011690	011690	011690
21		• TEST PLUG	3				034090	034090	034090	034090	034090	034090	034090	034090	034090	034090	034090	034090
22		• SCREW 1/4-20X3/4	13				001916	001916	001916	001916	001916	001916	001916	001916	001916	001916	001916	001916
23		• SCREW 10-24X3/8	2				001883	001883	001883	001883	001883	001883	001883	001883	001883	001883	001883	001883
24		• SCREW 6-32X7/16	1				004644	004644	004644	004644	004644	004644	004644	004644	004644	004644	004644	004644
25		• WASHER #6	1				002117	002117	002117	002117	002117	002117	002117	002117	002117	002117	002117	002117
26		• GROUND SCREW	1				001877	001877	001877	001877	001877	001877	001877	001877	001877	001877	001877	001877
27		• THRU WALL TERMINAL	5				003402	003402	003402	003402	003402	003402	003402	003402	003402	003402	003402	003402
28		• SNAP RING & WASHER	1				010167	010167	010167	010167	010167	010167	010167	010167	010167	010167	010167	010167
29		• SCREW S	4				012491	012491	012491	012491	012491	012491	012491	012491	012491	012491	012491	012491
□		REBUILD KIT	1				010166	010166	010166	010166	010166	010166	010166	010166	010166	010166	010166	010166

- Items included in Rebuild Kit. □ Not shown in illustration.

NOTES:

- See FM0160 parts price sheet for listing of parts pricing.
- "N/A" indicates not applicable.
- If an "X" follows model number or date of manufacture on brass I.D. tag, consult factory for ordering of this part.
- When replacing capacitor assembly on "REV. A" pumps only (Item 16), customer must also replace the case assembly (Item 2).
- When ordering motor housing (Item 6) or rotor and bearing (Item 7), specify either source or ZT motor. ZT stator can be identified by a completely round stator.

REPLACEMENT PARTS ILLUSTRATION FOR MODELS "N4270" AND "E4270"

