

MODEL 600XL & 600

1/2", 3/4", 1"



Item No.	Description	1/2"	3/4"	1"	600XL	600XLLPC	600XLLPV	600XLHT	600XLHR	600XLSC	610XL	600XLHLR	
1	STRAINER CAP	601-3XL	602-3XL	501-3XL-010F	●	●	●	●	●	●	●	●	
2	CAP WASHER	601A-12	503A-13	501A-12	●	●	●	●	●	●	●	●	★
3	SCREEN	601-41	602-41B	603-41	●	●	●	●	●	●	●	●	★
4	MAIN CAP	601-3XL	602-3XL	603-3AXL-010F	●			●	●	●	●		
	MAIN CAP	601-3XLLP	602-3XL	603-3AXL-010F		●	●					●	★
5	CAP WASHER	601A-12	503A-13	603A-12A	●	●	●	●	●	●	●	●	
6	WASHER	—	—	204-14A		●	●					●	
7	SPRING	602-33LPVS	602-33LPVS	602-33LPVS		●	●					●	
8	PLUNGER	601-34XL	602-34XL	603-34XL	●			●	●	●			
	PLUNGER	601-34XLLP	602-34XLLP	603-34XLLP		●	●					●	
	PLUNGER	611-34XL, 604C-12, 602B-11	612-34XL, 604C-12, 602B-11	613-34XL, 604C-12, 602B-11							●		
9	SEAT WASHER	601-12A	502-12	603-12A	●	●	●	●	●	●	●	●	★
10	WASHER	601-14	502-14	62-14	●	●	●	●	●	●	●	●	★
11	SEAT	601-18	602-18	603-18	●	●	●	●	●	●	●	●	
12	SEAT GASKET	501A-13	502A-13	603A-13	●	●	●	●	●	●	●	●	
13	UNION GASKET	601-13	62-13	63-13	●	●	●	●	●	●	●	●	
14	TAILPIECE NPT (FEMALE)	601-19XL	602-19XL	63-19XL	●	●	●	●	●	●	●	●	
	TAILPIECE NPT (MALE)	—	602M-19XL	63M-19XL	●	●	●	●	●	●	●	●	
	TAILPIECE COPPER (FEMALE)	601C-19	602C-19	63C-19	●	●	●	●	●	●	●	●	
	TAILPIECE COPPER (MALE)	—	602CM-19XL	63CM-19XL	●	●	●	●	●	●	●	●	
15	UNION NUT	601-9-010F	62-9-010F	63-9-010F	●	●	●	●	●	●	●	●	★
16	O-RING	011N	WK-111N	113N	●			●	●	●	●		★
	O-RING	011N	113N	113N		●	●					●	★
17	STEM	601-5XL	602-5XL	603-5XL	●			●	●	●	●		★
	STEM	601-5XL	602-5XLLP	603-5XL		●	●					●	★
18	TEFLON DIAPHRAGM	62-43HT	62-43HT	503-43HT			●	●					★
19	DIAPHRAGM	501-43	501-43	503-43	●	●	●	●	●	●		●	★
	DIAPHRAGM	511-43	511-43	513-43							●		★
20	DIAPHRAGM DISC	602-80	602-80	603-80	●	●	●	●	●	●	●	●	★
21	BOLT / NUT	501B-9	501B-9	503-11	●			●	●	●	●		★
	BOLT / NUT	501B-9	503-11	503-11		●	●					●	★
22	SPRING	62-33	62-33	603-33	●	●	●	●		●			★
	SPRING	601-33HR	601-33HR	503-33HR					●		●	●	★
23	SPRING DISC	602A-80	602A-80	602A-80	●	●	●	●	●	●	●	●	★
24	FRICTION RING	602B-12	602B-12	603B-12	●	●	●	●	●	●	●	●	★
25	WASHER	606C-12	606C-12	606C-12						●			
26	LOCKNUT	501B-9	501B-9	501B-9	●	●	●	●	●		●	●	★
	LOCKNUT SS	501B-9SS	501B-9SS	501B-9SS						●			
27	ADJUSTMENT BOLT	602A-11A	602A-11A	602A-11A	●	●	●	●					
	ADJUSTMENT BOLT	602A-11A	602A-11A	603A-11AHR					●		●	●	
	ADJUSTMENT BOLT SS	602A-11ASS	602A-11ASS	602A-11ASS						●			

- Item included in specified Model
- ★ Repair kit items (all ★ items in kit)

MODEL 600XL & 600

Parts Drawing

