





Thermal Fuse Location

When replacing the heat exchanger, thermal fuse must be properly installed and secured. Refer to the following illustration. Large HEX is shown as representative.



ITEM DESCRIPTION		PART NUMBER	RE199e	RE180e	RE160e	RE140e
002	Wall Bracket	109000281	2	2	2	2
004	Reinforcement Plate	109001248	1	1	1	1
005	Heat Protection Plate	109001249	1	1	1	1
006	Front Panel	109001251	1	1	1	1
007	Front Panel Upper Packing	109001252	1	1	1	1
008	Front Panel Lower Packing	109001253	2	2	2	2
009	Temperature Control	105000952	1	1	1	1
010	Temperature Control Plate	109001255	1	1	1	1
013	Thermistor Packing	109000490	1	1	1	1
016	Earth Plate	109001257	1	1	1	1
017	Latch Hook	109001258	2	2	2	2
018	Latch	109001259	2	2	2	2
019	Clamp Fixing Plate	109001260	1	1	1	1
020	Clamp	109001261	2	2	2	2
021	Rubber Stop	109000654	1	1	1	1
022	Rubber Stop	109001262	1	1	1	1
100	Gas Control Assembly	106000248	1	1	1	1
101	Test Port Set Screw	C10D-5	2	2	2	2
103	3/4 Gas Inlet	106000119	1	1	1	1
103	Burner Unit Assembly	106000250	1	1	1	1
103	Burner Unit Assembly - Small	106000249	1	1	1	1
105	Gas Pipe	106000251	1	1	1	1
110	Manifold Assembly - LPG	106000252	1	1	1	1
110	Manifold Assembly - LPG	106000253	1	1	1	1
110	Manifold Assembly - LPG	106000254	1	1	1	1
111	Manifold Assembly - NG	106000255	1	1	1	1
111	Manifold Assembly - NG	106000256	1	1	1	1
111	Manifold Upper Packing - Small	106000257	1	1	1	1
112	Manifold Lower Packing - Small	106000258	1	1	1	1
112	Manifold Lower Packing - Small	106000259	1	1	1	1
113	Top Side Reinforcement	109001264	1	1	1	1
116	Electrode	105000953	1	1	1	1
117	Flame Rod	105000954	2	2	2	2
118	Electrode Bracket - Right	109001265	1	1	1	1
119	Electrode Packing	109001266	1	1	1	1
120	Electrode Bracket - Left	109001267	1	1	1	1
123	Electrode Bracket Assembly	109001268	1	1	1	1
124	Fan Motor Assembly	105000955	1	1	1	1
125	Fan Motor	105000992	1	1	1	1
126	Fan Casing	108000128	1	1	1	1
128	Exhaust Duct Bracket	109001269	1	1	1	1
129	Combustion Chamber - Body Bracket	109001270	1	1	1	1
130	Combustion Chamber Bracket	109001271	2	2	1	1
131	Combustion Chamber Bracket - Small	109001272	1	1	1	1
135	Flue Outlet - Small	102000068	1	1	1	1
135	Flue Outlet - Small	102000069	1	1	1	1
136	Beltmouth	109001278	1	1	1	1
137	Seal Packing	109001280	1	1	1	1

ITEM DESCRIPTION		PART NUMBER	RE199e	RE180e	RE160e	RE140e
137	Seal Packing - Small	109001281	1	1	1	1
138	Front Panel Seal Packing	109001282	1	1	1	1
143	Heat Exchanger Assembly	104000313	1	1	1	1
143	Heat Exchanger Assembly - Small	104000315	1	1	1	1
400	Water Inlet	107000614	1	1	1	1
401	Water Flow Servo & Sensor	105000957	1	1	1	1
402	Rectifier	107000105	1	1	1	1
403	By-pass Servo Assembly	1090001284	2	2	1	1
404	Pipe Bracket	1090001285	1	1	1	1
405	Pipe Band	109001285	1	1	1	1
406	DI6 Pipe Bracket	107000092	1	1	1	1
408	Hot Water Outlet (3/4 NPT)	109001286	1	1	1	1
409	Stop Bracket	109001287	1	1	1	1
410	Gas Pipe Bracket	109000955	1	1	1	1
411	Bracket	109001287	1	1	1	1
412	Filter Assembly	H98-510-5	1	1	1	1
413	Cover	107000093	2	2	1	1
415	Hot Water Pipe Assembly	107000617	1	1	1	1
416	Hot and Cold Water Pipe Assembly	107000620	1	1	1	1
418	Clip	1090001288	1	1	1	1
418	Clip	109000244	1	1	1	1
460	Water Flow Turbine	107000621	1	1	1	1
461	Water Flow Turbine	107000088	1	1	1	1
726	CID	109000366	1	1	1	1
728	PC Board - Large	105000959	1	1	1	1
700	PC Board - Small 160	105000960	1	1	1	1
700	PC Board - Small 140	105000961	1	1	1	1
702	Cover	109001292	1	1	1	1
706	Ignitor	105000963	1	1	1	1
707	High Tension Cord	105000964	1	1	1	1
708	Electrode Sleeve	AU206-218	1	1	1	1
709	Water Inlet Thermistor	80500081	1	1	1	1
710	Heat Exchanger Thermistor	105000965	1	1	1	1
711	Clip	105000900	1	1	1	1
714	Fuse Holder	1090001295	3	3	3	3
715	Fuse Holder	1090001296	7	7	7	7
716	Heater Clip	AU124-618X01	3	3	3	3
717	Heater Clip	109000795	1	1	1	1
718	Heater Clip	AU100-721	2	2	2	2
719	Gas Control Harness	105000966	1	1	1	1
724	Sensor Harness - 2	105000969	1	1	1	1
725	Sensor Harness - 4	105000971	1	1	1	1
725	Fuse Harness - 1	105000976	1	1	1	1
726	Fuse Harness - 2	105000977	1	1	1	1
726	Power Supply Harness - 2	105000979	1	1	1	1
728	Ignitor Bracket	109001296	1	1	1	1
729	Cable Clip	109001297	1	1	1	1

ITEM DESCRIPTION		PART NUMBER	RE199e	RE180e	RE160e	RE140e
730	Twin Thermistor	105000982	1	1	1	1
731	Solenoid Harness	105000983	1	1	1	1
731	Solenoid Harness - Small	105000984	1	1	1	1
732	Outside Temperature Thermistor	105000296	1	1	1	1
740	Heater	105000986	1	1	1	1
742	Heater	105000989	1	1	1	1
743	Over Heat Switch	105000991	1	1	1	1
800	Screw	1090001298	4	4	4	4
801	Screw	109000649	8	8	8	8
802	Screw	Z8A4048UJK	2	2	2	2
803	Screw	CP-40452	1	1	1	1
804	Screw	ZFAB04085Z	3	3	3	3
805	Screw	109000598	26	26	26	26
806	Screw	109001299	9	9	9	9
807	Screw	809000179	2	2	1	1
808	Screw	809000177	18	18	18	18
809	Screw	U217-449	2	2	2	2
810	Screw	1090001300	1	1	1	1
811	O-ring	109001301	3	3	3	3
812	O-ring	M10B-2-14	1	1	2	2
813	O-ring	109000252	3	3	1	1
817	O-ring	109000252	2	2	2	2
818	Packing	109000181	1	1	1	1
820	Screw	108000021	4	4	4	4
821	Screw	CP-20883-410UK	2	2	2	2
822	Screw	CP-30383	3	3	3	3
823	Screw	109000641	19	19	19	19
824	Screw	109000793	2	2	2	2
828	Screw	109001306	2	2	2	2
830	O-ring	M10B-13-4	2	2	2	2
831	O-ring	M10B-2-4	3	3	3	3
834	Screw	109001304	5	5	5	5
835	Screw	109000648	1	1	1	1
836	Screw	109001305	2	2	2	2
888	Manual	100000722	1	1	1	1
889	Trash Sheet	100000735	1	1	1	1

