
Chest Freezer

PRODUCT MODEL NUMBERS

MZC31T15D
MZC3122F


Electrical: A 115 Volt, 60 Hz., AC only 15- or 20-amp fused (or circuit breaker), grounded electrical supply is required. It is recommended that a separate circuit serving only your freezer be provided. Use an outlet that cannot be tur ned off by a switch or pull chain. Do not use an extension cord.

PRODUCT DIMENSIONS



Model Numbers	Model Size	Width “A”	Height “B”	Depth “C”
MZC31T15D	14.8 cu. ft.	47⅜" (120.3 cm)	33⅜" (84.8 cm)	30¼" (76.8 cm)
MZC3122F	21.7 cu. ft.	66¼" (168.3 cm)	33⅜" (84.8 cm)	30¼" (76.8 cm)

LOCATION REQUIREMENTS



IMPOR TANT: Do not install the freezer near an oven, radiator or other heat source.

Check the str ength of the floor before installing your freezer. It should hold the weight of a freezer fully loaded with food.

Allow at least 3" (7.5 cm) of air space on both sides of the freezer and 2" (5 cm) between the back of the freezer and the wall. Leave room above the freezer to open the lid.

Your freezer operates most efficiently when located in an area where the temperature is normally between 32°F (0°C) and 110°F (43°C).

Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice.

Dimensions are for planning purposes only. For complete details, see Installation Instructions packed with product. Specifications subject to change without notice.

Ref. W10675482B
02/16