



**REPAIR
PARTS
LIST**

Model No.(s)

**110.78062801
(White)**

**To Call
Toll Free
For Parts:**

**1-800-366-PART
(1-800-366-7278)**

For Service:

**1-800-4-MY-HOME
(1-800-469-4663)**



GAS DRYER

The model number of your gas dryer is found on the serial plate located in the door well.

All repair parts listed are available for immediate purchase or special order when you visit your nearest Sears Service Center, or the Service Department at most Sears stores. To order parts by phone, call the toll free parts number listed to the left.


When requesting service or ordering parts, always provide the following information:

- | | |
|----------------|--------------------|
| ◆ Product Type | ◆ Part Number |
| ◆ Model Number | ◆ Part Description |

Sears, Roebuck and Co., Hoffman Estates, IL 60179 U.S.A.

TOP AND CONSOLE PARTS

For Model: 110.78062801
(White)



TOP AND CONSOLE PARTS

For Model: 110.78062801
(White)


Illus. No.	Part No.	DESCRIPTION
1		Literature Parts
	W10156035	Tech, Sheet
	W10180628	Guide, Use & Care
	W10164637	Guide, Quick Start
	W10035727	Tip Sheet
		Gas
	W10139322	Tip-Sheet Steam Dry

Following May Be Purchased

DO-IT-YOURSELF REPAIR MANUALS

2	W10218132	Console Assembly
3	W10218312	Assembly, User Interface
4	8572038	Cover, UI-Assembly
5	8571937	Knob, Assembly
6	W10111623	Control Electronic
7	3395683	Connector (Motor)
8	8557504	Medallion
9	8563853	Bracket, Machine Controller
10	W10003770	Screw
11	3347243	Connector, 6-Circuit Assembly
12	8558863	Bracket, Console
13	8558859	Top
14	3407184	Harness, User Interface
15	337686	Screw, 8-18 x 1/2
16	8558853	Screw, Grommet (3)
17	353424	Connector Sensor
18	W10185554	Foam-Top
19	W10163629	Harness, Wiring Main
20	3391018	Tie, Cable
21	3936144	Connector
22	94614	Terminal
23	3394427	Clip, Harness
24	3403498	Connector, 3-Position (Gas Valve)
25	W10001580	Screw (3)
26	717252	Receptacle, 2-Way
27	3403499	Connector, 2-Position (Gas Valve)

(White)



CABINET PARTS

For Model: 110.78062801
(White)


Illus. No.	Part No.	DESCRIPTION
1	W10007520	Clip, Ground
2	8544753	Bracket, Burner
3	3390631	Screw, 10-16 x 3/8
4	8558833	Plate, Cover Terminal Block
5	8564012	Switch, Assembly
6	344020	Cord, Power
7	W10183827	Cabinet
8	3392100	Foot, Dryer
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)
9	660658	Clamp, Motor (2)
10	3387374	Spring, Idler
11	3389420	Retainer, Idler
12	W10001340	Nut, Fly Wheel
13	8547160	Pulley Assembly
14	W10201446	Bracket-Gas Pipe
15	8578560	Plug-Hole
16	8539892	Wire, Motor (To Belt Switch)
17	8577312	Assembly, Dry Rack

Illus. No.	Part No.	DESCRIPTION
18	W10167613	Wire-Belt Switch (To Protector)
19	3394083	Clip, Front Panel (2)
20	W10111888	Plug Strike
21	8579717	Assembly, Hinge (2)
23	8564011	Bracket, Switch
24	W10100830	Screw, 10-16 x 3/64
25	8558850	Filler, Big Mouth Axial
26	3393657	Restrainer, Belt
27	8547170	Motor, Assembly 60 HZ.
28	W10140148	Panel, Rear
29	8544743	Pulley, Blower
30	8547157	Belt, Drive
31	8576626	Wheel, Fly
32	8547158	Bracket, Motor
33	W10111905	Catch, Door Assembly

Illus. No.	Part No.	DESCRIPTION
34	W10002600	Screw, 6-20 x 1 1/4
35	8568303	Locator, Snap Down (2)
36	8577310	Dry Rack (Top)
37	8577852	Dry Rack (Bottom)
38	W10144494	Plug, Hole
39	W10111903	Seal, Door
40	3400805	Screw
41	W10201785	Door Switch Assembly
42	8547171	Pulley, Drum Motor
43	8576625	Lock, Top Front
44	W10044490	Seal, Front Panel
45	8564457	Plug, Front Panel
46	238088	Hinge Top (2)
47	8571356	Door, Inner
48	18849	Pad, Top Hinge (2)
49	8571361	Door, Outer
50	8564010	Assembly, Switch & Actuator
51	W10111883	Panel, Front
52	W10111906	Assembly, Strike & Plate
53	W10157932	Foam-Seal Cabinet

BULKHEAD PARTS

For Model: 110.78062801
(White)



BULKHEAD PARTS


For Model: 110.78062801

(White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8575324	Shaft, R.H. Thread	23	3394985	Outlet Housing Assembly	37	8544737	Wheel, Blower
2	8577274	Thermistor, Blower Housing	24	8573070	Clip, Lint Duct	38	3977373	Bracket, Light
3	90767	Screw, 8-18 x 3/8	25	8557269	Complete Drum Assembly	39	W10168632	Socket, Assembly
4	3394986	Spring, Lint Screen Door	26	97787	Screw, 11-16 x 3/4	40	W10044579	Washer, Nozzle
5	8544757	Air Duct Assembly	27	W10116344	Seal, Drum	41	W10044628	Nut, 9/16 - 1/32
6	697813	Seal, Outlet Housing	28	W10130506	Valve & Hose Assembly (Complete)	42	8573713	Thermal Cut-Off
7	8573068	Seal, Blower Cover	29	W10129424	Valve & Bracket Assembly	43	8573028	Thermostat, High-Limit
8	3934666	Nut, 3/8 x 16(R.H.)	30	693995	Screw	44	8544735	Housing, Blower
9	8544739	Motor, Blower	31	W10154992	Nozzle & Hose Assembly (Includes Items. 31,33,40 & 41)	45	8544786	Lint Duct Assembly
10	8557244	Bulkhead Front	32	W10133422	Hose, Nylon (Not Servicable) (Service With 31.)	46	8573824	Funnel, Burner
11	W10109200	Screw, 11-16 x 3/4	33	W10044629	Nozzle & Screen Assembly	47	W10160575	Cover, Myst Valve
12	487909	Screw, 8-15 x 1/2	34	3387223	Electrode, Sensor	48	338906	Sensor, Radiant
13	8544721	Seal, Lint Duct	35	3402841	Lens, Drum Light	49	W10044615	Clip, Push-To-Connect
14	3394984	Door, Lint Screen	36	3406124	Bulb, Light	50	8544719	Cover, Blower (Includes No.7)
15	8544755	Exhaust Pipe				51	3387230	Screw, 10-16 x 13/16
16	W10001120	Nut, 3/8-16 (L.H.)				52	W10044605	Coupling, Hose
17	W10139797	Bulkhead, Rear				53	8563860	Baffle, Drum
18	3387459	Washer, Support				54	3350424	Screw
19	8575325	Shaft, L.H. Thread				55	8544718	Duct-Inlet Blower
20	690997	Ring, Tri				56	W10159631	Sleeve-Tube
21	8536973	Roller, Support				57	8544723	Grill, Outlet
22	8539889	Harness, Flame Switch				58	3390719	Thermal Fuse
						59	8544741	Bracket-Housing Blower (2)
						60	W10049370	Lint, Screen
						61	8544742	Belt, Blower

**For Model: 110.78062801
(White)**

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	8557891	Burner Assembly 60 Hz. (Type 1) (White Rodgers)	9		Orifice, Burner Type 1	14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
2	8573010	Tube, Burner		15418	Type 1			
3	694298	Bracket, Ignitor		15422	Type 4 (Butane)			
4	686590	Ignitor		229742	Type 4 (Propane)			
5	3393909	Screw & Washer (8-32 x 7/8)	10	8573071	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).	15	694424	Leak, Limiter
6	343641	Screw, 10-16 x 1/2				16	694423	Screw, Regulator Adjustment
7	8544751	Base, Burner	11	694421	Screw, 8-32 x 1/2 (2)	17	694422	Spring, Regulator
8	3387057	Screw, 8-18 x 3/8	12	8182790	Bracket, Coil	Following Parts Not Illustrated		
			13	694540	Coil, 60 Hz. (2 Terminal) (Main)		8576846	Conversion Kit (Type 1) to Type (4) LPG).

OPTIONAL PARTS (NOT INCLUDED)

For Model: 110.78062801
(White)

Illus. No.	Part No.	DESCRIPTION
---------------	-------------	-------------

ACCESSORY PARTS

80047	Kit, Dryer Repair
8522199	Kit, Dryer Vent Testing
346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)
49611	Kit, Side Venting
8544761	Tube, Extension

PAINT, TOUCH-UP (1/2oz.)

72017	White
-------	-------

PAINT, PRESSURIZED SPRAY (12 oz.)

350930	White
350938	Primer, Gray

PAINT, BULK (1 qt.)

799344	White (Uncut)
--------	---------------

Miscellaneous Parts Bag

W10044609	Bag-Assembly (Contains The Following)
76314	Hose, Inlet 6'Hose With Elbow
W10044603	Hose, Inlet 1' Hose
3976300	Washer
W10044604	Connector Hose "Y"