




UNDERCOUNTER DISHWASHER

MODELS:

WDF320PADB0 (Black)
WDF320PADW0 (White)
WDF320PADT0 (Biscuit)
WDF320PADS0 (Stainless)
WDF320PADD0 (Universal Silver)

DOOR AND PANEL PARTS




DOOR AND PANEL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts
	W10435040	Installation Instructions
	W10656410	Energy Guide
	W10644344	Use & Care Guide
	W10590887	Tech Sheet, English
	W10590888	Tech Sheet, French
2		Arm, Hinge
	W10274922	Left Hand
	W10274921	Right Hand
3	W10195120	Stiffener, Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4		Panel Front
	W10274895	Black
	W10274896	White
	W10274897	Biscuit/Bisque
	W10274902	Stainless
	W10274898	Universal Silver
5		Access Panel
	W10369023	Black
	W10369025	White
	W10369027	Biscuit/Bisque
6	W10315897	Insulation, Front Panel

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	8268961	Sleeve, Friction
8		Fastener
	W10503548	Black
	W10503549	White
	W10503550	Biscuit/Bisque
9	304392	Screw
10	489470	Screw
11	W10300769	Insulation, Toe Panel

CONTROL PANEL AND LATCH PARTS




CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)
	W10671909	Black
	W10671910	White
	W10671911	Biscuit/Bisque
2	W10401190	Box, Connector

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3		Handle, Latch
	W10716685	Black
	W10716686	White
	W10127606	Biscuit/Bisque
4	W10274884	Bolt, Latch
5	W10348413	Screw
6	8524471	Actuator, Latch

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10629133	Control, Electronic
8	W10372484	Brace, Connector
9	W10274880	Switch, Door
10	W10350294	Button Tree
11	W10350295	Light Pipe
12	W10678341	Spring, Latch

INNER DOOR PARTS




INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348413	Screw
2	W10254547	Inner Door Assembly (Also Order Item 4)
3	W10482094	Cover, Dispenser
4	W10254545	Gasket, Vent

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
5	W10254548	Deflector, Vent (Also Order Item 4)
6	W10671922	Dispenser Assembly
7	W10612054	Wiring Harness
8	W10177098	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
9	8269296	Seal, Door/Console
10	W10462232	Bracket, Dispenser
11	W10524920	Cap, Rinse Aid


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	370445	Clamp, Hose	6	371505	Clamp, Hose	12	W10316267	Standpipe, Overfill
2	8531412	Hose	7	W10327250	Fill Valve Assembly	13	W10345285	Float & Retainer Assembly
3	W10195536	Inlet, Water (Also Order Item 4)	8	304392	Screw	14	W10195037	Lever, Overfill Switch
4	8531323	Gasket	9	W10688890	Drain Loop with Check Valve Assembly	15	W10292152	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)
5	W10508676	Nut, Inlet (Also Order Item 4)	10	304231	Screw			
			11	W10195039	Switch, Overfill Control			

TUB AND FRAME PARTS




TUB AND FRAME PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10349288	Tub Assembly (Includes Heater Assembly)
2	W10321574	Shield, Thermostat
3	W10524469	Seal, Tub
4	W10341745	Screw
5	3367670	Screw
6	8269145	Bracket, Undercounter
7	W10304231	Support, Bottom

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
8	W10619352	Leveler, Leg
9	W10337934	Spring, Door Balance
10	8270016	Wheel And Mount Assembly
11	3400892	Screw
12	8268991	Cover, Terminal Box
13	W10380479	Shield, Tub Sound
14	W10539489	Clip, Thermostat

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
15	3371618	Thermostat
16	8580309	Strike, Latch
17	3378128	Washer, Pronged Cup
18	3400014	Screw, Grounding
19	8268990	Bushing, Door Spring
20	W10195368	Sound Insulation, Bottom


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10455271	Cover, Outlet	7	W10693534	Filter Cup Assembly	16	W10445975	Hose Assembly (Includes 2 Clamps)
2	W10482462	Sump With Seal (Also Order Items 13 & 16)	8	W10348269	Pump, Drain	17	W10319027	Lower Sprayarm
3	W10463906	Screen	9	8269144	Hose, Drain			
4	W10529161	Motor (Also Order Items 13 & 16)	10	W10348407	Screw			
5	W10605059	Sump & Motor Assembly	11	370445	Clamp, Hose			
6	W10372113	Tab, Sump	12	W10134017	Indicator, Optical Wash			
			13	W10538166	Grommet			
			14	W10169167	Clamp, Hose			
			15	W10195086	Motor, Isolator			

UPPER WASH AND RINSE PARTS




UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10340747	Feed Tube Assembly
2	W10165274	Screw

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10317197	Sprayarm
4	W10340683	Manifold

HEATER PARTS




HEATER PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10441445	Heater Element Assembly
2	W10446558	Washer, Heater
3	W10477552	Nut, Heater Element

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	8269262	Bracket, Heater Support
NOTE: If heater element is removed, it must be replaced.		


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10164198	Dishrack, Upper	4	8565925	Stop, Track (Non-Removable)	7	8268826	Clip, Cupshelf
2	8575281	Mount, Wheel Assembly	5	W10306228	Track, Spacer	8	W10082861	Stop, Track (Removable)
3	3385089	Track, Dishrack	6	8268828	Cupshelf, Small			

LOWER RACK PARTS



LOWER RACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	8561705	Dishrack, Lower
2	8268645	Wheel & Transport Assembly
3	8562045	Basket, Silverware (Assembly)

OPTIONAL PARTS (NOT INCLUDED)

ACCESSORIES

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		SIDE PANEL KITS
	8171656	White
	8171657	Black
	8171658	Biscuit/Bisque
	8171659	Stainless Steel
		MOISTURE BARRIER KIT
	4396277	Barrier Kit
		DRAIN HOSE
	3385556	12 Ft.

PAINT, TOUCH-UP (1/2OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	72017	White
	72032	Black
	4392899	Biscuit/Bisque

PAINT, PRESSURIZED SPRAY (12 OZ.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	350930	White
	285006	Black
	4392901	Biscuit/Bisque

PAINT, BULK (1 QT.)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	799344	White
	4392900	Biscuit/Bisque

POWER CORD KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	4317824	Power Cord Kit (Included Cord & Misc. Hardware)

ANTI-TIP KIT

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
	8171477	Floor Mount Kit
	8212560	Side Mount Kit

DISHRACK REPAIR

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
		TINE TIP REPAIR KIT (Enough for Two Complete Racks)
	4396838	White
	4396840	Grey
	4396854	Silver Atlantis
		VINYL TOUCH-UP (4oz)
	676453	White
	676455	Grey
	4396853	Silver Atlantis