


KitchenAid®

UNDERCOUNTER DISHWASHER

MODELS:

KDTM404EBL1 (Black)
KDTM404EWH1 (White)
KDTM404ESS1 (Stainless Steel)
KDTM404EBS1 (Black Steel)


DOOR AND PANEL PARTS



DOOR AND PANEL PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1		Literature Parts	6		Panel, Front (Includes 4, 10, 11 & 16)	13	304392	Screw
	W10741197	Installation Instructions		W10796429	Black	14	W10692757	Barrel Nut, Front Panel
	W10746817	Energy Guide		W10796430	White	15	3400071	Screw
	W10762967	Use & Care Guide		W10796428	Stainless	16		Nameplate
	W10750907	Tech Sheet, English		W10796432	Black Steel		W10518672	Grey
	W10750908	Tech Sheet, French	7	W10687133	Set Screw	17	W10315897	Insulation, Front Panel
2		Arm, Hinge	8	W10735304	Insulation, Four Layer	18	8269016	Clip, Ground
	8534854	Left Hand	9		Handle Assembly	19		Toe Panel
	8534853	Right Hand		W10786161	Stainless		W10737729	Black
3	W10844384	Barrier, Vapor	10	W10195726	Stud, Mounting		W10751505	White
4	W10696150	Screw	11	W10794483	Light Pipe	20	W10641745	Bracket, Control
5		Access Panel	12		Screw			
	W10195777	Black		302868	Black			
	W10195778	White		3400836	White			

CONTROL PANEL AND LATCH PARTS




CONTROL PANEL AND LATCH PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Console Assembly (Includes Insert)
	W10686311	Black
	W10686320	White
2	W10653840	Latch Assembly (Includes Switch)

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
3	W10566919	Jumper, 4 Wire
4	W10348408	Screw
5	W10789000	Control, Electronic
6	W10195237	Clip, Control

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
7	W10194937	Brace, Connector
8	W10756253	Box, Connector

INNER DOOR PARTS




INNER DOOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10348409	Screw
2	8281217	Screw
3	W10712594	Inner Door Assembly

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
4	W10667473	Seal, Door Bottom
5	W10771404	Seal, Console/Door

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
6	W10620296	Dispenser Assembly
7	W10566923	Wiring Harness


FILL, DRAIN AND OVERFILL PARTS



FILL, DRAIN AND OVERFILL PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10195037	Lever, Overfill Switch	10	W10647205	Housing, Overfill	18	W10653312	Outlet, Air Assembly
2	W10769066	Hose			(Also Order Item 11)			(Also Order Item 19)
3	W10584470	Inlet, Water (Also Order Item 4)	11	8531743	Gasket, Flat	19	W10653310	Seal, Rubber
4	8531323	Gasket	12	W10195038	Nut, Standpipe	20	W10653319	Nut, Air Assembly
5	W10213825	Nut, Water Inlet (Also Order Item 4)	13	W10195036	Float & Retainer Assembly			(Also Order Item 19)
6	371505	Clamp, Hose	14	W10786175	Miscellaneous Parts Bag (Contains 2 Screws, 2 Clamps, & 2 Brackets)	21	W10673168	Blower Assembly
7	W10327250	Fill Valve Assembly	15	370445	Clamp, Hose	22	W10653323	Nozzle, Airduct
8	3390631	Screw	16	W10651070	Drain Loop with Check Valve Assembly	23	W10770367	Tube, Exhaust
9	W10734532	Switch, Overfill Control	17	W10772907	Vent Hose	24	W10653320	Clip, Retainer


TUB AND FRAME PARTS



TUB AND FRAME PARTS

<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus. No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10681497	Tub Assembly (Also Includes Heater Assembly)	14	W10348411	Screw	27		Spacer, Tub/Brace
2	W10713315	Assembly, Terminal Box	15	W10190778	Wheel Leg		W10195630	Left Hand
3	W10300924	Gasket, Tub	16	W10619352	Leveler, Leg		W10195631	Right Hand
4	W10813122	Plug, Tub	17	3378128	Washer, Pronged Cup	28	W10681564	Support Assembly, Rear
5	W10544004	Strike, Latch	18	8270020	Spring, Door Balance	29	W10337661	Strain Relief
6	304392	Screw	19	3400014	Screw, Grounding	30	W10750120	Insulation, U-Wrap
7	W10835073	Seal, Cabinet	20	W10653292	Cover, Terminal Box	31	W10486051	Retainer
8	W10746772	Sound Insulation, Bottom	21	W10158291	Cable, Door	32	W10380173	Sound Insulator, Tub Lip
9	W10084086	Door Balance Assembly	22	W10292870	Shield, Thermostat	33	W10309090	Screw
10	3367670	Screw	23	304666	Retainer	34	W10696509	Heater Element Assembly (Includes Heater Washer & Nut)
11	8269145	Bracket, Undercounter	24	W10796452	Shield, Tub Sound			NOTE: If heater element is removed, it must be replaced.
12	3400074	Screw	25	W10300703	Bracket, Thermostat			
13	W10622469	Mount, Lower Track Assembly	26	W10195091	Thermostat			


PUMP, WASHARM AND MOTOR PARTS



PUMP, WASHARM AND MOTOR PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10713293	Motor (Also Order Items 9 & 11)	9	W10647237	Hose Assembly (Includes 2 Clamps)	20	W10380239	Ring, Volute
2	W10647236	Motor, Isolator	10	W10673257	Motor & Sump Assembly	21	W10753070	Capacitor
3	W10715847	Cover, Outlet	11	W10538166	Grommet	22	8533949	Nut
4	W10647213	Sump with Seal (Also Order Items 9 & 11)	12	W10348407	Screw	23	W10708008	Housing, Pump
5	9741232	Screw	13	W10372113	Tab, Sump	24	W10467002	Screw
6	W10647226	Grate Assembly, Course	14	W10758882	Pump, Drain	25	W10169167	Clamp, Hose
7	W10792724	Sprayarm Assembly, Lower	15	8269144	Hose, Drain	26	W10713292	Pump Assembly
8	W10713298	Filter Assembly, Pump	16	W10476221	Disc, Diverter	27	W10772270	Spring, Compression
			17	W10380170	Motor, Diverter	28	W10713294	Impeller Assembly
			18	8269146	Clamp, Hose	29	W10723279	Volute
			19	W10705575	Indicator, Optical Wash	30	W10710432	Shield, Capacitor


UPPER WASH AND RINSE PARTS



UPPER WASH AND RINSE PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10753067	Feed Tube Assembly (Includes Items 2 & 3)	4	W10788845	Manifold	7	W10355006	Tube, Connecting
2	W10327455	Sprayarm, Third Level	5	W10448645	Sprayarm, Upper	8	W10622462	Manifold, Tall Item Zone
3	3400918	Retainer	6	W10767752	Manifold, Proscrub			


UPPER RACK AND TRACK PARTS



UPPER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10312791	Dishrack, Upper	7	W10082649	Cupshelf Assembly	14	W10082853	Clip, Pivot
2		Housing, Adjuster (Includes Spring and Lever)	8	9741232	Screw	15	8539102	Positioner, Dual Dishrack
	W10588164	Left Hand	9	W10250162	Cover, Adjuster	16	W10082848	Clip, Cupshelf
	W10588165	Right Hand	10		Track, Assembly	17	W10702379	Basket, Utensil Row
3	W10250160	Clip, Adjuster		W10781301	Left Hand	18	W10309090	Screw
4	W10546503	Adjuster Assembly		W10781305	Right Hand	19	W10473792	Handle, Dishrack Rear
5	W10195839	Strap, Tether Adjuster	11	W10778309	Handle, Dishrack Front			
6	W10195840	Positioner, Adjuster	12	8562030	Tine Row, Fold Down			
			13	W10752617	Clip, Dispenser Guard			



LOWER RACK AND TRACK PARTS



LOWER RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	W10713334	Dishrack, Lower	6	W10473835	Lid, Silverware Basket	9	W10713283	Retainer, Sliding Tine
2		Support, Front Ski	7		Support, Rear Carriage	10	W10482109	Row Basket, Utensil
	W10473813	Left Hand		W10473807	Left Hand			
	W10473817	Right Hand		W10473809	Right Hand			
3	W10473836	Basket Assembly, Silverware	8	W10554952	Tine Row, Sliding			
4	W10056272	Tine Row, Fold Down						
5		Track Assembly						
	W10781307	Left Hand						
	W10781311	Right Hand						

THIRD LEVEL RACK AND TRACK PARTS



THIRD LEVEL RACK AND TRACK PARTS

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
1		Track Assembly
	W10653357	Left Hand
	W10653356	Right Hand

<u>Illus.</u> <u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	W10653326	Rack, Third Level
3	W10309090	Screw

