



Feature Access Codes Quick Reference Guide

Feature Access Codes are codes that can be entered through the phone keypad to control the configuration of certain features. To use a Feature Access Code, off-hook the phone and enter the appropriate Feature Access Code (see below). For features that require additional input, follow the audible prompts to input the required additional information.

Feature/Service	Code
Call Forwarding Always Activation	*72
Call Forwarding Always Deactivation	*73
Call Forwarding Always To Voice Mail Activation	*21
Call Forwarding Always To Voice Mail Deactivation	*24
Call Forwarding Busy Activation	*90
Call Forwarding Busy Deactivation	*91
Call Forwarding Busy To Voice Mail Activation	*40
Call Forwarding Busy To Voice Mail Deactivation	*42
Call Forwarding No Answer Activation	*92
Call Forwarding No Answer Deactivation	*93
Call Forwarding No Answer To Voice Mail Activation	*41
Call Forwarding No Answer To Voice Mail Deactivation	*45
Call Forwarding Not Reachable Activation	*94
Call Forwarding Not Reachable Deactivation	*95
Caller ID Delivery Blocking per Call	*67
Caller ID Delivery Blocking Persistent Activation	*31
Caller ID Delivery Blocking Persistent Deactivation	*32
Caller ID Delivery per Call	*65
Call Park	*68
Call Retrieve	*88
Cancel Call Waiting	*70
Clear Voice Message Waiting Indicator	*99
Direct Voice Mail Transfer	*55
Directed Call Pickup	*97
Directed Call Pickup with Barge-In	*33
Do Not Disturb Activation	*78
Do Not Disturb Deactivation	*79
Group Call Park	*58
Group Call Pickup	*98
Last Call Return	*69
Last Number Redial	*66
Music On Hold Per-Call Deactivation	*60
Push to Talk	*50

Note: Not all station types support all features. If the station being used does not support a feature associated with a given Feature Access Code, the feature access code will not work for that station.