Cisco IP Conference Phone 7832



Your Phone

① Mute bar

2 LED bar

③ Softkey buttons

(4) Navigation bar and Select button

5 Volume key

LED Bar States

The LED bar illuminates to indicate status:

- Green, solid-Active call
- Green, flashing-Incoming call
- Green, pulsing-Held call
- Red, solid-Muted call

Make a Call

Enter a number and press Call.

Answer a Call

Press Answer.

Put a Call on Hold

- 1. Press Hold.
- 2. To resume a call from hold, press Resume.

View Your Recent Calls

Press **Recents** or press the up navigation key.

View Your Favorites

Press **Favorites** or press the down navigation key to see your speed-dial numbers.

Add Another Person to a Call

- 1. From an active call, press Conf.
- 2. Enter a number.
- 3. Press Conf.

Transfer a Call to Another Person

- 1. From a call that is not on hold, press Transfer.
- 2. Enter the other person's phone number.
- 3. Press Transfer again.

Mute Your Call

1. Press Mute

2. Press Mute again to turn mute off.

Listen to Voice Messages

Press **Messages** and follow the voice prompts.

Forward All Calls

1. Press Fwd all.

- 2. Dial the number that you want to forward to, or press Messages.
- 3. When you return, press Fwd off.

Adjust the Volume in a Call

Press **Volume** up or down to adjust the volume when the phone is in use.

Adjust the Ringer Volume

Press **Volume** up or down to adjust the ringer volume when the phone is not in use.

Change the Ringtone

- 1. Select Settings > Preferences > Ringtone.
- 2. Scroll through the list of ringtones and press **Play** to hear a sample.
- 3. Press Set and Apply to save a selection.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)