





FSMA Intro Monitor Arm - Single



Assembly Directions
Montageanleitung
Instructions de montage
Instrucciones de montaje



C-Clamp C-Klammer Pince en C Pinza en C



FSMA Intro Monitor Arm - Single






Pads cannot be repositioned once glued





Pads können nach dem Verkleben nicht mehr neu positioniert werden

Les patins ne peuvent pas être repositionnés une fois collés




Una vez pegadas las almohadillas no pueden ser reposicionadas



FSMA Intro Monitor Arm - Single




FSMA Intro Monitor Arm - Single




FSMA Intro Monitor Arm - Single

Through Mount Durchgehende Montage Pince traversante A través del soporte


14




15





16



17



FSMA Intro Monitor Arm - Single



Service and contact details

Service und Kontaktdaten
Service après-vente et coordonnées
Información de contacto y asistencia

Manufacturer

Produzent
Fabricant
Fabricante

Steelcase GmbH
Brienner Str. 42
80333 München

Phone Telefon Téléphone Teléfono
+49 (0) 80 31 405 – 111

Email

DE lineone-de@steelcase.com
EN lineone-en@steelcase.com
FR lineone-fr@steelcase.com
ES posventaspain@steelcase.com

