


FrameOne Plus



Assembly Directions
Montageanleitungen
Instructions de montage
Istruzioni di montaggio
Montage instructies

Type 10 Standard / Loop - fixed top 2-5

Typ 10 Standard / Loop - feste Platte
Type 10 Standard / Loop - plateau fixe
Tipo 10 Standard / Loop - piano fisso
Type 10 Standaard / Loop - vast blad

Type 10 Standard / Loop - sliding top (facility manager) 6-9

Typ 10 Standard / Loop - Schiebeplatte
Type 10 Standard / Loop - plateau coulissant
Tipo 10 Standard / Loop - piano scorrevole
Type 10 Standard / Loop - schuifblad

Type 10 Standard / Loop - user slide 10-13

Typ 10 Standard / Loop - Nutzer-Schiebeplatte
Type 10 Standard / Loop - plateau coulissant version utilisateur
Tipo 10 Standard / Loop - piano scorrevole per l'utente
Type 10 Standard / Loop - schuifblad gebruikersversie

Type 10 Eco 14-17


Typ 10 Eco
Type 10 Eco
Tipo 10 Eco
Type 10 Eco

Type 16 18-20




Typ 16
Type 16
Tipo 16
Type 16

FrameOne Plus

Assembly Directions






Type 10 Standard/Loop - fixed top
 Typ 10 Standard/Loop - feste Platte
 Type 10 Standard/Loop - plateau fixe
 Tipo 10 Standard/Loop - piano fisso
 Type 10 Standaard/Loop - vast blad












Top 25mm / Top 14mm



6x

6x

















FrameOne Plus







Assembly Directions





Type 10 Standard/Loop - sliding top
Typ 10 Standard/Loop - Schiebeplatte
Type 10 Standard/Loop - plateau coulissant
Tipo 10 Standard/Loop - piano scorrevole
Type 10 Standaard/Loop - schuifblad



















FrameOne Plus

Assembly Directions




Type 10 Standard/Loop - user slide
Typ 10 Standard/Loop - Nutzer-Schiebeplatte
Type 10 Standard/Loop - Plateau coulissant version utilisateur
Tipo 10 Standard/Loop - piano scorrevole per l'utente
Type 10 Standaard/Loop - Schuifblad gebruikersversie









$L > 1600\text{mm} = \text{8} - \text{11}$




8




9a




9b




10



11








FrameOne Plus

Assembly Directions



Type 10 Eco
Typ 10 Eco
Type 10 Eco
Tipo 10 Eco
Type 10 Eco









Top 25mm / Top 14mm




8x


8x






FrameOne Plus









FrameOne Plus

Assembly Directions



Type 16
Typ 16
Type 16
Tipo 16
Type 16



8x



2x



8x

