








SOFT EDGE for Universal Systems Worksurface



- 1. Remove (9) screws attaching the Soft Edge to worksurface as shown.
- 2. Push up on the bottom of Soft Edge to dislodge it from the worksurface.
TIP: Push up from one end first, then the other end.



Bins for components removed

STEEL	SCRAP
	