

Removal &/or Installation of Glides or Casters

Task Chair

1. To remove glide or caster, tap base with a rubber mallet while pulling on the glide or caster.
2. If the glide or caster pulls off without the stem, use pliers to pull on the stem while tapping the base with a rubber mallet.
3. Press the glide or caster into the base assembly.

Stool

1. To remove glide or caster, tap base with a rubber mallet while pulling on the glide or caster.

NOTE: The stem will remain in the base after the glide or caster is removed.

2. Press the glide or caster onto the remaining stems in the base assembly.

If you have a problem, question, or request, call your local dealer, or Steelcase Line 1 at **888.STEELCASE** (888.783.3522) for immediate action by people who want to help you. (Outside the U.S.A., Canada, Mexico, Puerto Rico, and the U.S. Virgin Islands, call: 1.616.247.2500) Or visit our website: www.steelcase.com

© 2000 Steelcase Inc.
Grand Rapids, MI 49501
U.S.A.

Printed in U.S.A.

