



MIDBACK
(SHOWN WITH CUSHION)



HIGHBACK
(SHOWN WITH CUSHION & BACK)



POUF

If you have a problem, question, or request, call
your local dealer, or Coalesse at 1.800.627.6770
Or visit our website: www.coalesse.com

© 2009 Coalesse
San Francisco, California U.S.A.
Printed in U.S.A.



Installing the Seat Cushion Only

1. Place seat cushion onto chair. Locate the ball and string to the right and left hand sides of the chair.




2. Press button on ball inward (2a) and slide ball off string (2b).

3. Slide string through chair webbing.

4. Place each ball back onto string and slide upward (4a) so it fits snugly under chair webbing (4b).




2b




Installing the Seat Cushion and Back Cushion


1. On the back cushion, locate each ball and string. There are five (5) total. Press button on ball inward (1a) and slide ball off string (1b).



2. Lower back cushion onto seat cushion (2a) and carefully thread all five (5) strings through each eyelet (2b).



3. Place back cushion onto chair.



4. Perform steps 3 and 4 on page 2 to complete the installation.

Installing the Seat Cushion onto a Pouf

1. Press button on ball inward (1a) and slide ball off string (1b).
2. Lower seat cushion onto the pouf.
3. Slide each string through pouf webbing.
4. Perform step 4 on page 2 to complete the installation.

