


# Installation Guide for Virtual Tensile Tester


Updated: 2/16/2017

## Procedure

1. Download the file from the following link: [Virtual Tensile Tester Installer](#)
2. Unzip the folder to an accessible location, such as the desktop.



3. Right-click on `virtual_tensile_tester` and select Open With... and open with **Internet Explorer, Firefox, or Chrome.**



4. The simulator will launch in your browser. If this doesn't happen, try a different browser, and see the information below:

**\*\* Note: you must have Adobe Flash Player installed for Internet Explorer in order for this simulator to run. You can download Adobe Flash Player at <http://get.adobe.com/flashplayer/otherversions/> and follow the on page installation instructions. \*\***