

# INSTALLATION GUIDE FOR CNC MOTION CLASSROOM INSTALLATION

# Technology used in

Ø

Updated: 8/3/2021

The process for receiving a Classroom license for CNC Motion and Robocell has changed. Schools will need to request a license from the Intelitek website listed in the instructions below. To have the process move quickly, please know that email address that your CIM teacher uses to log in to myPLTW. Teacher or IT can fill out the form, and both can receive the follow up email with the license. Please see other notes below about the guide and installation process.

- This is a standalone license and not a network license
- These instructions are for the 6000, 8000, Super, or Expert Mill only. They will not work for the Prolight 1000 Mill.
- If imaging, DO NOT activate the master image. There are special imaging instructions at the end of the document
- This process takes up to 3 business days to receive the licensing, and about 20 minutes install.
- You can download and install the software while waiting for your license to process.

## Before you start


- Disable your anti-virus program.
- Have Administrative Rights to license CNC Motion
- Uninstall previous versions of CNC Motion for licensing to work correctly






# License Request Procedure

1. Go to <a href="https://intelitek.com/pltw-schools-information-page/">https://intelitek.com/pltw-schools-information-page/</a> and select Request Software License



2. Fill out the form with the CIM Trained teacher's email that they use to log in to myPLTW, as well as correct school information.








3. List the equipment that you have in your lab, and the software that you need. As an option, you can also list an IT contact name who will also receive the license.



4. Submit your request at the bottom of the page. It will take up to 3 business days for intelitek to send the license to the contacts listed on the form. The license is not required to download, install, and image the software. Feel free to move to the installation procedure portion of the document.

### Installation Procedure


- Go to https://downloads.intelitek.com/PLTW/ICNC/
- Select DOWNLOAD









3. Right click and select Extract all on the iCNCSetup.zip file from the folder where you downloaded it.



4. Select iCNCSetup.exe to run the installer.




5. Select Next








#### 6. Select Yes




7. Select CNCMotion for Intelitek CNC & Fanuc emulator. Then select Next.








8. Select BenchMill 6000 Machining Center. Then select Next.




9. Select machine configuration are common for all users. Then select Next.








#### 10. Select Next




#### 11. Select Install








12. Select Yes, I want to restart my computer now.



\*\* If using imaging software, do not license the software. Gather the image, and deploy it. License the software after all the machines are imaged. DO NOT license the Master Image. More information on imaging is at the end of the document \*\*

13. After your computer restarts, right-click on CNC Motion and select run as administrator. If no desktop icon, or start menu option is available, run iCNCConfig as an administrator from C:\Program Files (x86)\Intelitek\CNCMotion for Intelitek CNC & Fanuc emulator








14. If prompted for CNC Configuration, select OK then Yes.



15. Select Activate AND enter the license that you received from intelitek.











#### 16. The license is now active.




# Imaging considerations

Your school's serial number can now be pre-populated during the imaging process. After installation on the "Golden image," take the following steps.

- 1. Go to the following folder: C:\ProgramData\Intelitek\Licenses\CNCMotionV6\_2020
- 2. Open the file SerialCode.txt



3. Copy and past your serial number into the file, and Save the file.



## Silent installation instructions

Silent installation instructions can be found on the intelitek website here: <a href="https://downloads.intelitek.com/Manuals/CNC/iCNC\_v6.1\_SilentInstall\_v2.1.pdf">https://downloads.intelitek.com/Manuals/CNC/iCNC\_v6.1\_SilentInstall\_v2.1.pdf</a>

