

GYBE | FUSION PANEL SETUP INSTRUCTIONS



THANK YOU FOR YOUR PURCHASE!

If you have questions about installation, maintenance, or take down, please call us at (800)426-9496. Our goal is that you are completely satisfied with our products. Please read this installation manual carefully and follow all instructions contained herein. Please note that the installer is responsible for the site selection, installation and use. Do not erect during inclement weather and follow all safety procedures during the installation and take down process.

Please contact all utility companies for underground services. In many states, the utilities work together and have formed a Utility Locating Service. It is your responsibility to locate all the underground services, including speaking to the owner about irrigation, pool and other special services that they may have installed. Also, please note that special precautions should be taken such that any overhead powerlines are duly noted and avoided during the tent erection process.



TentCraft Inc in no way represents the estimated holding power to be true in all cases. It is an estimate, and as such, does not imply that the figures are sufficient to hold any tent securely in windy or adverse weather conditions. The tent installer accepts sole responsibility for the safe installation, teardown, and maintenance of any tent. TentCraft does not represent in any way that the materials provided with the purchase of the tent are sufficient enough to hold it up in windy or adverse weather conditions. There is no way for TentCraft to know the site conditions or the weather conditions at the event. This leaves us unable to recommend the adequate amount of holding power needed to hold the tent safely in position. Furthermore, we are not responsible for the methods which the installer uses to erect the tent or anchor it in position. Installers MUST be empowered to deem the tent unsafe for occupancy if/when the weather becomes unstable.

Step 1



Align two GYBE tents of the same size next to each other.

Locate one of the zippers on the fusion panel. Find the zipper pull and ensure that it is at the beginning of the zipper.

Step 2



Attach the zipper pull on the fusion panel to the beginning of the zipper found on the tent. The tent zipper will be located between the bladder and the roof material. It may be necessary to pull back the roof material to reveal the zipper - as it can be quite taut against the bladder.

Step 3



Zip the fusion panel in completely along the curve of the tent opening. Once zipped, run the Velcro straps on the bottom of the fusion panel through the metal brackets found on both legs of the tent.

Step 4



Repeat steps 2-4 on the opposite side of the fusion panel, connecting it to the second tent.

Step 5



Adjust the tents' placement so that the fusion panel is taut and straight.

Step 6



Once zipped, run the Velcro straps on the bottom of the fusion panel through the metal brackets found on both legs of the tents.