

# HALF HEIGHT WALL SETUP INSTRUCTIONS



# THANK YOU FOR YOUR PURCHASE!

If you have questions about installation, maintenance, or take down, please call us at (800)426-9496. Our goal is that you are completely satisfied with our products. Please read this installation manual carefully and follow all instructions contained herein. Please note that the installer is responsible for the site selection, installation and use. Do not erect during inclement weather and follow all safety procedures during the installation and take down process.

Please contact all utility companies for underground services. In many states, the utilities work together and have formed a Utility Locating Service. It is your responsibility to locate all the underground services, including speaking to the owner about irrigation, pool and other special services that they may have installed. Also, please note that special precautions should be taken such that any overhead powerlines are duly noted and avoided during the tent erection process.



**TentCraft Inc in no way represents the estimated holding power to be true in all cases. It is an estimate, and as such, does not imply that the figures are sufficient to hold any tent securely in windy or adverse weather conditions. The tent installer accepts sole responsibility for the safe installation, teardown, and maintenance of any tent. TentCraft does not represent in any way that the materials provided with the purchase of the tent are sufficient enough to hold it up in windy or adverse weather conditions. There is no way for TentCraft to know the site conditions or the weather conditions at the event. This leaves us unable to recommend the adequate amount of holding power needed to hold the tent safely in position. Furthermore, we are not responsible for the methods which the installer uses to erect the tent or anchor it in position. Installers **MUST** be empowered to deem the tent unsafe for occupancy if/when the weather becomes unstable.**

## Step 1



Locate the half-wall bar kit: consisting of two longer bars with clamps on one side and a shorter connector bar to join the two.

## Step 2



Press the push button on the connector piece in and slide it into the longer half wall bar until it snaps into place. Repeat this step with the push button on the opposite end of the connector bar. The result is one long half-wall bar with clamps at both ends.

## Step 3



To attach the half-wall bar to the tent legs, twist off the black knob on the outside of both clamps and remove the L Clamps. Place the L clamp attached to the half-wall bar on both tent legs directly below the push buttons on the legs.

## Step 4



Replace the L clamps that were removed back onto the bolt so that the clamp is enclosed around the leg. Replace the black knob onto each bolt and tighten them to hold the half-wall bar onto the tent legs.

## Step 5



Unfold the half-wall and locate the top edge that is lined with white keder (a small plastic cylinder sewn into the top edge of the wall). Slide this keder into the track found along the bottom edge of the half-wall bar.

## Step 6



Unhook the Velcro on the left and right sides of the walls. Wrap the opened flaps around the tent legs on each side and re-attach the hook Velcro to the loop Velcro. This will hold the wall taut across the side of the tent.