

TIMOTHY STONE WATCHES

Congratulations on purchasing your Timothy Stone® watch.

Please read these instructions carefully to understand how to operate your Timothy Stone timepiece.



For more information, please visit:

www.timothystone.com


HOW TO START YOUR WATCH

To start your watch remove the plastic guard from under the crown, then press the crown in against the case. The second hand will begin advancing in one-second intervals.

PLEASE NOTE: SOME TIMOTHY STONE WATCHES HAVE DECORATIVE SUB-DIALS ON THE FACE OF THE WATCH. IF THE HANDS DON'T MOVE WHEN PULLING OUT THE CROWN, IT MOST LIKELY IS DECORATIVE.

TO SET TIME:

- 1) PULL crown all the way out and turn to correct time.
- 2) Push crown in to restart. For screw-in setting crown, push crown in while turning CLOCKWISE to tighten.



Watches with date: Note correct time of day (A.M or P.M.) for proper date function.

TO SET DAY:

- 1) PULL crown to "middle" position and turn CLOCKWISE until correct day appears. If day does not change, pull crown to "out" position and turn CLOCKWISE or COUNTERCLOCKWISE through necessary number of 24 hour periods until correct day appears.