


CONNECTION

MD-50S MD-50S

- 1 _____ 1
- 2 _____ 2
- 3 _____ 3
- 4 _____ 4
- 5 _____ 5
- 6 _____ 6
- 7 _____ 7
- 8 _____ 8
- 9 _____ 9
- 10 _____ 10
- 11 _____ 11
- 12 _____ 12
- 13 _____ 13
- 14 _____ 14
- 15 _____ 15
- 16 _____ 16
- 17 _____ 17
- 18 _____ 18
- 19 _____ 19
- 20 _____ 20
- 21 _____ 21
- 22 _____ 22
- 23 _____ 23
- 24 _____ 24
- 25 _____ 25
- 26 _____ 26
- 27 _____ 27
- 28 _____ 28
- 29 _____ 29
- 30 _____ 30
- 31 _____ 31
- 32 _____ 32
- 33 _____ 33
- 34 _____ 34
- 35 _____ 35
- 36 _____ 36
- 37 _____ 37
- 38 _____ 38
- 39 _____ 39
- 40 _____ 40
- 41 _____ 41
- 42 _____ 42
- 43 _____ 43
- 44 _____ 44
- 45 _____ 45
- 46 _____ 46
- 47 _____ 47
- 48 _____ 48
- 49 _____ 49
- 50 _____ 50
- Shell _____ Shell



TOLERANCES	
UNIT	mm
SCALE	1/1
PROJECTION	First Angle

DataStorageCables.com

PRODUCT
EXTERNAL SCSI CHANGER ADAPTER

1	MD 50PIN FEMALE	2	DWN. LIAN 10.06.'99	PART NO. B300	SHEET 1/1
NO.	DESCRIPTION	Q'TY	CHKD.	DWG NO.	REV A