

Keurig

1. To fill machine, remove the water reservoir from brewer by first removing lid from reservoir, then lift reservoir straight up and away from brewer (may be tight). Fill to MAX FILL line with fresh water. Replace reservoir on brewer and cover with lid.
2. Press the Power Button found directly above the LCD Control Center and allow the machine to heat the water (about 4 minutes). While “NOT READY” is displayed, do not lift the handle.
3. Once the water is heated, “READY TO BREW” will display and the Brew Buttons will illuminate.
4. Place a mug on the drip tray plate.
5. Lift the silver handle to insert your selected K-Cup.

NOTE: Do not remove the foil lid or puncture the K-Cup.

6. Lower the handle completely to close the lid and select your brew size by pushing the corresponding “Mug” button.



If the brewer does not brew, lift and re-lower handle, check water levels and make sure the water reservoir is properly inserted.

If the display shows “PRIME” and the blue light in the water reservoir is flashing, remove the water reservoir, thoroughly clean, refill fully and return it to the brewer

(ensuring it is seated properly).

