


Use ▲ or ▼ to adjust the refrigerator and freezer temperatures.

- When you initially touch the temperature setting icons, the most recent setting is displayed.
- Approximately five seconds after adjusting the setting, the display will automatically show the actual cooling temperature.

The Ventilation switch is used to re-circulate cool air:

- You can use the switch to chill large quantities of food fast.
- We recommended you use the ventilation fan if room temperatures or humidity are high.

If the power failure LED  is lit, the freezer temperature has risen too **high** during the last few hours. The freezer temperature display flashes and if you touch the **Alarm** icon, the highest temperature registered will be displayed for about one minute.

The SuperCool feature switches the refrigerator to maximum cooling to cool large quantities of food rapidly. The refrigerator returns to normal cooling after six hours.

