

## Thermostat

When you press the “+” or “-” button, the temperature will remain at this set point temporarily until the next program period begins.



Fan Switch: ON will run the fan continuously. AUTO will cycle the fan on only when the heating or cooling system is on.

System Switch: Selects the operation mode on your HVAC system. Selecting **HEAT** turns on the heat mode. Selecting **COOL** turns on the cool mode. Selecting **OFF** turns both heating and cooling off.

The glow-in-the-dark light button along the top of the unit will self-illuminate for several hours after exposure to ambient light. This button turns on the display light when pressed.

