

Coffee Maker

1. To fill machine, remove the water reservoir from brewer by first removing lid from reservoir, then lift reservoir straight up and away from brewer (may be tight). Fill to MAX FILL line with fresh water. Replace reservoir on brewer and cover with lid.
2. Press the power button to allow the machine to heat the water. Once the water is heated, the red heating light will turn off and the “Mug” buttons will illuminate.
3. Place a mug on the drip tray plate.
4. Lift the silver handle to insert your selected K-Cup.

NOTE: Do not remove the foil lid or puncture the K-Cup.

5. Lower the handle completely to close the lid and select your brew size by pushing the corresponding “Mug” button.



If the brewer does not brew, lift and relower handle, check water levels and make sure the water reservoir is properly inserted.