

Critical product information

- 1) The fridge MUST have a minimum of 100mm ventilation at the back and 50mm on the sides and top of the fridge for ventilation.
- 2) The grill at the lower back and lower front MUST be cleaned of dust and debris once per month. Use a soft brush and an air blower to achieve this.
- 3) Ambient room temperature MUST NOT exceed and be maintained a few degrees below 38°C / 65% humidity for correct operation.
- 4) Keep the door closed as much as possible, as compressor will over stress and ice will form if the fridge/freezer is opened frequently, especially during summer.
- 5) There is no heater on the door and condensation will form
- 6) The fridge MUST NOT be exposed to direct or indirect sunlight (such as through glass windows or skylights) or positioned near a heat source..
- 7) There MUST be good air flow in your area. The fridge MUST not be placed in an area with a low or stagnant airflow.

***** IMPORTANT - READ**

Please open the attached document and/or visit the websites listed below. Before you make a purchase, read and double-check all technical information, specs, disclaimers, warranties, and Terms and Conditions. If you continue with the transaction, you acknowledge that you have read all legally needed documentation and agree to all terms and conditions, disclaimers, and warranty information.

<https://www.agequipment.com.au/>

<https://www.agequipment.com.au/pages/warranty>

<https://www.agequipment.com.au/pages/terms-and-conditions>

*** Please compare product dimensions to your installation space, door frame, and corridor measures to guarantee adequate ventilation and maneuverability. An order cannot be cancelled once it has been placed. If an item is returned and a refund is sought, a restocking fee of 25% of the item plus freight back to AG Equipment will be levied. The original delivery fee will not be refunded. Products and measurements can be found at www.agequipment.com.au. ***