

apuro

Hamburger Machine

Instruction manual



**Model:
CE225-A**

Safety Tips

- Position on a flat, stable surface.
- A service agent/qualified technician should carry out installation and any repairs if required.
- Consult Local and National Standards to comply with the following:
 - Health and Safety at Work Legislation
 - Fire Precautions
 - Building Regulations
- Not suitable for outdoor use.
- Keep all packaging away from children. Dispose of the packaging in accordance to the regulations of local authorities.

Introduction

Please take a few moments to carefully read through this manual. Correct maintenance and operation of this machine will provide the best possible performance from your Apuro product.

Pack Contents

The following is included:

- Apuro Hamburger machine
- Handle
- Instruction manual

Apuro prides itself on quality and service, ensuring that at the time of packaging the contents are supplied fully functional and free of damage.

Should you find any damage as a result of transit, please contact your Apuro dealer immediately.

Operation

Clean all parts thoroughly with warm soapy water before using the hamburger machine. Dry thoroughly.

Preparation

- Follow the manufacturers guidelines on the appropriate way to prepare the grease proof paper, these can be loaded into the paper holder.
- Prepare the hamburger mix.


Making the hamburgers

1. Screw the handle onto the lever.
2. Push the Handle fully back so that the Press has lifted out and to the side of the bowl.
3. Press the Release button so that the plate inside the bowl drops.
4. Place a piece of the grease proof paper inside the bowl.
5. Fill the bowl with the desired amount of mix.
6. Place a piece of grease proof paper on top of the mix.
7. Ensuring that fingers are away from the bowl, pull the handle forwards such that the Press compresses the mix.



WARNING: Fingers must be kept away from the Bowl during the Pressing process.

8. Push the handle fully back and the hamburger will lift out of the bowl.



Cleaning, Care & Maintenance

- Do not use any abrasive cleaning agents on the appliance. Use warm soapy water.
- Always dry thoroughly after cleaning.
- An Apuro agent or qualified technician should carry out repairs if required.

Technical Specifications

Model	Hamburger diameter	Dimensions (h x w x d mm)	Weight (empty)
CE225-A	100mm	290 x 210 x 275 mm	5.24kg

Compliance

Apuro parts have undergone strict product testing in order to comply with regulatory standards and specifications set by international, independent, and federal authorities.



All rights reserved. No part of these instructions may be produced or transmitted in any form or by any means, electronic, mechanical, photocopying, recording or otherwise, without the prior written permission of Apuro.

Every effort is made to ensure all details are correct at the time of going to press, however, Apuro reserve the right to change specifications without notice.

apuro

CE225-A_A5_v1_20190305