



Machine	Explode	Code	Description
CK829-A Apuro Kitchen Kettle 3.5Ltr	1	☎	Lid Knob
CK829-A Apuro Kitchen Kettle 3.5Ltr	2	☎	Handle
CK829-A Apuro Kitchen Kettle 3.5Ltr	3	☎	Lid Sheet
CK829-A Apuro Kitchen Kettle 3.5Ltr	4	☎	Lid
CK829-A Apuro Kitchen Kettle 3.5Ltr	5	☎	Dash Plate
CK829-A Apuro Kitchen Kettle 3.5Ltr	6	☎	Screw
CK829-A Apuro Kitchen Kettle 3.5Ltr	7	☎	Kettle Body
CK829-A Apuro Kitchen Kettle 3.5Ltr	8	☎	Handle Sheet
CK829-A Apuro Kitchen Kettle 3.5Ltr	9	☎	Steamer Tube
CK829-A Apuro Kitchen Kettle 3.5Ltr	10	☎	Steamer Cover
CK829-A Apuro Kitchen Kettle 3.5Ltr	11	☎	Strix Thermostat
CK829-A Apuro Kitchen Kettle 3.5Ltr	12	☎	Plastic Cover
CK829-A Apuro Kitchen Kettle 3.5Ltr	13	☎	Button
CK829-A Apuro Kitchen Kettle 3.5Ltr	14	☎	Power Cord
CK829-A Apuro Kitchen Kettle 3.5Ltr	15	☎	Seal Ring
CK829-A Apuro Kitchen Kettle 3.5Ltr	16	☎	Element
CK829-A Apuro Kitchen Kettle 3.5Ltr	17	☎	Foot