


☎ Technical & Spares helpline 1300 225 960
sales@nisbets.com.au

Machine	Explode	Code	Description
Apuro Bakery Convection Oven with Steam 66Ltr	1	AW263	Door Seal
Apuro Bakery Convection Oven with Steam 66Ltr	2	AW264	Door Assembly
Apuro Bakery Convection Oven with Steam 66Ltr	3	AW180	Manual Humidity Button
Apuro Bakery Convection Oven with Steam 66Ltr	4	AW174	Timer
Apuro Bakery Convection Oven with Steam 66Ltr	5	AW175	Timer Knob
Apuro Bakery Convection Oven with Steam 66Ltr	6	AW176	Power Indication Light
Apuro Bakery Convection Oven with Steam 66Ltr	7	AW177	Working Indication Light
Apuro Bakery Convection Oven with Steam 66Ltr	8	AW178	Temperature Knob
Apuro Bakery Convection Oven with Steam 66Ltr	9	AW179	Thermostat
Apuro Bakery Convection Oven with Steam 66Ltr	10	AW181	Feet (set 4)
Apuro Bakery Convection Oven with Steam 66Ltr	11	AW182	Door Switch
Apuro Bakery Convection Oven with Steam 66Ltr	12	AW265	Shelf
Apuro Bakery Convection Oven with Steam 66Ltr	13	AW183	Internal Light
Apuro Bakery Convection Oven with Steam 66Ltr	14	AP644	Wire Buckle
Apuro Bakery Convection Oven with Steam 66Ltr	15	AW185	Temperature Limiter
Apuro Bakery Convection Oven with Steam 66Ltr	16	AW266	Terminal
Apuro Bakery Convection Oven with Steam 66Ltr	17	☎	AUS Power Cord
Apuro Bakery Convection Oven with Steam 66Ltr	18	AW268	Fan Motor Clockwise
Apuro Bakery Convection Oven with Steam 66Ltr	19		Fan Blade Clockwise
Apuro Bakery Convection Oven with Steam 66Ltr	20	AW269	Heating Element
Apuro Bakery Convection Oven with Steam 66Ltr	21	AW270	Fan Motor Anti-Clockwise
Apuro Bakery Convection Oven with Steam 66Ltr	22		Fan Blade Anti-Clockwise
Apuro Bakery Convection Oven with Steam 66Ltr	23	AW190	Water Pump
Apuro Bakery Convection Oven with Steam 66Ltr	24	AW191	Rebound Device
Apuro Bakery Convection Oven with Steam 66Ltr	25	AW192	Water Tank

☎ Technical & Spares helpline 1300 225 960
sales@nisbets.com.au