Dosing Pump Accessories for Water Treatment GRUNDFOS DOSING ACCESSORIES

Grundfos offers a comprehensive range of accessories covering every requirement when dosing with Grundfos pumps. Our range of service kits enables you to perform high-quality pump service and maintenance with original spare parts, keeping your dosing solution in perfect shape for years.





CABLES AND PLUGS

Cables and plugs are used for the connection of the dosing pump to external control devices, such as process controllers, flow meters, start/stop contacts and level control units.



E-BOX 150 PROFIBUS / E-BOX 200 MODBUS

The Grundfos E-Box is a Plug-and-play Profibus fieldbus communication interface for the integration of SMART Digital DDA dosing pumps into a Profibus or Modbus network. Fieldbus communication allows to use the DDA dosing pump in industrial automation systems, where advanced remote control and monitoring functions are required.



INSTALLATION KITS

A basic installation kit includes an injection unit with spring-loaded nonreturn valve, 6 metres of PE discharge hose, 2 metres of PVC suction hose, 2 metres of PVC deaeration hose and a foot valve with strainer and weight, without or with level indication.



ADAPTERS FOR SUCTION LANCES AND FOOT VALVES WITH LEVEL INDICATION These adapters allow the installation of standard suction lances (G 2 thread) and foot valves with level indication (PE cap) on different types of containers.



RIGID SUCTION LANCES RSL

Rigid suction lances are installed at the lower end of the inlet hose. They are available without level indication or with low-level and empty-tank indication. Their immersion depth is adjustable.

Suction lances include a strainer, a nonreturn valve, a hose and pipe connection set, an adjustable tank connection with holes for a deaeration line.

Variants with low-level end empty-tank indication include additionally a Reed-switch unit with two floaters, 5 metres of cable with PE jacket, an M 12 plug to connect a DDA, DDC, DDE or DDI dosing pump.

FOOT VALVES FV

Foot valves are installed at the lower end of the inlet hose. They are available either without level indication or with low-level and empty-tank indication. Foot valves include a weight, a strainer, a non-return valve, a hose connection set (4/6 mm, 6/9 mm, 6/12 mm and 9/12 mm) and a pipe connection set (threaded, Rp ¼", female).



be think innovate

DOSING ACCESSORIES



INJECTION UNITS

Injection units connect the dosing line with the process line. They ensure a minimum backpressure of 0.7 bar, and avoid backflow of the dosing liquid. In general, they include an injection pipe, a spring-loaded non-return valve with Tantal spring, a hose and pipe connection set.



INJECTION UNITS FOR SPECIAL APPLICATIONS

Hot-injection units with ball valve can be used for direct injection of dosing liquid into processes with a temperature of up to 120°C.

Further injection units for special applications are available:

- Injection units with ball valve
- Injection units with lip valve
- Injection units with removable injection pipe



MULTI-FUNCTION VALVES MFV

Multi-function valves combine the functions of pressure relief valves and pressure loading valves. In addition, they allow deaeration of the pump and emptying of the discharge line for maintenance.

Loading pressure and relief pressure are adjustable. A multi-function valve is mounted directly on the dosing pump.



PRESSURE LOADING VALVES PLV

Pressure loading valves are installed in the outlet line after the pressure relief valve, and after the pulsation damper, if fitted. Loading pressure is adjustable.



PRESSURE RELIEF VALVES PRV Pressure relief valves are installed in the outlet line near the pump, using the 2 inline connections. The side connection

2 inline connections. The side connection leads the relief liquid back into the tank. Relief pressure is adjustable.

Visit grundfos.us/pei to learn more about Department of Energy (DOE) pump energy index (PEI) requirements and PEI ratings on specific Grundfos models.





PULSATION DAMPERS

Pulsation dampers are used to even out the pulsating flow and pressure produced by positive displacment pumps like diaphragm dosing pumps. They can be installed before and after the pump.

DOSING TANKS

Cylindrical dosing tanks are available transparent or black in seven sizes between 40 and 100 l. Square tanks are available transparent for 100 l. Square tanks allow the assembly of two dosing pumps. All dosing tanks include a litre scale and are prepared for the assembly of dosing pumps and inlet-side accessories.

COLLECTING TRAYS

Collecting trays are available in several sizes to suit the respective dosing tank size. They collect chemicals that might leak out of the tank, and protect the environment. All collecting trays are made of transparent PE.

HANDHELD MIXERS

With a handheld mixer, the liquid in a tank is mixed by moving the stamping plate up and down. The shaft length can be adapted to suit the selected tank, and fixed with a DN 15 through bolt on top of the tank.

ELECTRIC STIRRERS

Electric stirrers are intended for the mixing and dissolving of non-abrasive, non-inflammable and non-explosive liquids. Electric stirrers are designed to match cylindrical Grundfos dosing tanks. With a frequency of 50 Hz they run at approx. 1500 rpm, and are suitable for liquids with low to medium viscosity.



www.grundfos.us www.grundfos.ca www.grundfos.mx