

### Features

- Station provides staff controls for room-level presence, request, code, staff emergency, staff rounding, and room reset functions
- Four configurable buttons
- Default button layout is L1, L2, Staff Emergency, and L3
- Button label insert options are provided for the 5 configurations available (see list below)
- Illuminated faceplate for low light visibility
- UL/cUL® 1069 and UL® 2560 Listed
- The Config Tool software has a built in label maker which allows customizing the button legend



SF124 Staff Peripheral Station

### Description

The SF124 Staff Peripheral Station provides staff presence, staff request and staff rounding with programmable schedules, if so configured. Pressing a presence button activates an associated colored lamp on the associated corridor light. The connection to the IR42xP5-series station is supervised. Two-wire connections provide simple wiring.

Default button options (layouts included):

- L1, L2, Staff Emergency, L3 (Default)
- L1, L2, Staff Emergency, Reset
- L1, L2, L3, Reset
- L1, Code, Staff Emergency, Reset
- Round, Code, Staff Emergency, Reset

### Required Components

NC455CE Central Equipment Module  
IR42xP5-series Station  
IH121K or IH122K Single and Dual Station Mounting Kits

### Specifications

Dimensions:	4.58"H × 3.25"W × 1.03"D (116 mm × 83 mm × 26 mm)
Environment:	0°C–60°C
Construction:	PC board with quality electronic components mounted to a membrane on a flame-retardant (UL® 94V-0) plastic faceplate
Mounting:	Attach the IH121K/IH122K back plate to a standard single-gang ring or single-gang ring and box
Housing:	Standard single-gang box
Connections:	2-wire flying lead

### Listings



UL® 1069 Listed and cUL® Listed to CSA C22.2 No. 205; UL® File Number E71599.



RoHS Compliant.