KINZE VISION
FIRMWARE UPDATE INSTRUCTIONS:

Before you begin, you will need a SanDisk Compact Flash Card.

1. Click **Firmware Download** for the Cobalt
2. When the File Download box pops up click on **Save**
3. Another window will pop up and select where you would like to save the .zip file. Default is to your desktop. Click **Save** (Your modem speed will determine how long it will take to download the file)
4. When the download is complete click **Close** on the download window
5. From the Desktop (or location you saved the file in) find the folder with a zipper on it. **Right click** and select **Extract All**.
6. Follow the Extraction Wizard steps. If you do not change where the file is saved to, it will default to save to your Desktop again.
7. Click **Finish**. A window will open with the extracted file. Leave it open.
8. Insert the SanDisk Compact Flash Card into your computer (a 2nd window will open)
9. Take the file in the Desktop window and copy to the SanDisck Compact Flash Card window (Left click on the file and drag it between windows OR right click on the file in the Desktop window, select copy, right click in the SanDisk Compact Flash Card window, right click, select paste)
10. Take the SanDisc Compact Flash Card out of the computer
11. With monitor display ON, insert the SanDisck Compact Flash Card into the Card Slot on the display and close the door
12. Press **Upgrade** in the lower part of the Home Screen
13. Select the current firmware version and press **Accept**
14. Follow the on-screen instructions
15. Remove SD Memory Card from the Monitor

The monitor is now updated and field ready.