

Instructions on how to calibrate the 200g and 500g electronic pocket scales

Requires a calibration weight and new batteries

1. Turn the unit on with no weight and wait until the display is stable
2. Press and HOLD the 'UNITS' button until the display shows a weight which takes around 1-2 seconds, then release the button. (lower left button)
3. Repeatedly click the 'Tare' button to display the value of the weight you have.
4. Click and release the 'UNITS' button once, the display will briefly show 'CAL', then will start flashing the weight - The scales are now ready for weight reference.
5. Place the calibration weight on the scales.
6. After the weight has stabilized the display will show 'PASS' and switch off, the scales are now calibrated. This process should be repeated with all the available weights.
7. To check: Remove the weight and turn the scales on, the display should show 0.00g, place the weight on the scales again, the scales should read the weight correctly.

