

Lectro-Temp Control™

Care & Instructions

Made in China
K&H Manufacturing, LLC
Colorado Springs, CO
www.khmfg.com | (877) 738-5188



Thank you for purchasing K&H Manufacturing's LECTRO TEMP CONTROL™. When used properly, this unit should provide years of hassle free service.

USE & CARE INSTRUCTIONS

Read all instructions carefully. This is an electrical product, pay special care to IMPORTANT SAFEGUARDS.

- 1** Plug your LECTRO TEMP CONTROL™ into a 110-120 volt electrical outlet protected from weather, water or possible animal damages.
- 2** Plug your LECTRO-KENNEL™ heated pet pad into the LECTRO TEMP CONTROL™ unit.
- 3** Turn knob counterclockwise to high position. This allows full current to reach the heating element. Wait 1-2 hours.
- 4** Test pad warmth by placing hands on the LECTRO-KENNEL™ for 10-15 seconds to feel the radiant heat.
- 5** Turn adjustment knob clockwise slightly. Wait 30 minutes or more and test pad heat by using above procedure.

6 Continue above step until desired temperature is achieved.

7 You can decide on different day and night settings as long as outside conditions don't change radically.

8 NEVER plug more than one LECTRO-KENNEL™ into the LECTRO TEMP CONTROL™.

K&H Limited One Year Warranty

Our warranty is as follows: K&H Manufacturing warrants to the original consumer, that this product will be free of defects and workmanship for a period of one year from the date of purchase. The manufacturer's liability hereunder is limited to replacement of the product. This warranty is void if the product has been damaged by accident, unreasonable use, neglect, tampering, or other causes not arising from defects in material or workmanship.

To exercise your warranty: If, during the warranty period, your product malfunctions, return it to the place of purchase with your **original purchase receipt**. If this cannot be done, return the product, postage prepaid, to K&H Manufacturing, with **dated proof of purchase or original date receipt**. A return authorization number, obtained by calling (719) 591-6950 must accompany all returns to manufacturer. Please include a note explaining the problem when returning the product.