

C•CURE 9000 V2.80 Integration with Commend Intercom V4.1.108.0 Release Notes

C•CURE 9000 v2.80 Integration with Commend Intercom Version 4.1.108.0 Release Notes

September 2019

This Release Note file provides important information for the C•CURE 9000 v2.80 Commend Intercom Integration for both server and client machines. (In case of discrepancy, the information in this document supersedes the information in any document referenced herein.)

Please read this file before installing the product.

Contents

1. [Overview](#)
2. [Contents of Installation](#)
3. [Requirements](#)
4. [Limitations](#)
5. [Installation](#)

1. Overview

The C•CURE 9000 Commend Intercom Integration is a product that integrates Commend Intercom systems with the C•CURE 9000 Security and Event Management System.

There are no new features in this release.

2. Contents of Installation

The installation contains the following files:

- setup.exe – Installation program for the Commend Intercom Integration.
- CC9K-2-80-Com-IntGd-8200-1191-1092-A0-en.pdf – *C•CURE 9000 v2.80 Commend Intercom Integration Guide*
- CC9K-2-80-Com-RN-8200-1191-1093-A0-en.pdf – *C•CURE 9000 v2.80 Commend Intercom Integration Release Notes*

3. Requirements

The C•CURE 9000 Commend Intercom Integration product requires the following software versions:

- C•CURE 9000 Security and Event Management System v2.80
- Commend Intercom 4.1.108.0
- Commend Intercom Integration, Models GE100, GE200, GE300, GE700, and GE800

4. Limitations

- The C•CURE Monitoring Station does not provide access to Commend Intercom objects from the Explorer Bar Hardware section.
- When you create a new Partition in the C•CURE 9000 Administration Workstation, the Details and Template Details tabs on the Partition Editor do not display Commend Intercom objects.

- There can be only one connection to a Lantronix at a time. Do not configure more than one Commend Central (from different C•CURE 9000 servers) the same IP address and TCP port.
- The C•CURE 9000 Commend Intercom Integration is only capable of supporting station numbers up to 4 digits in length. Station numbers with 5 or more digits must be reprogrammed with a 4 digit station number in order to be used with C•CURE 9000.

5. Installation

See the *C•CURE 9000 v2.80 Commend Intercom Integration Guide*.

End of Release Notes

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

© 2019 Tyco Security Products.
All Rights Reserved.