

Expose® II 256

Phenolic Disinfectant Cleaner



An extremely versatile phenolic disinfectant cleaner for use on hard, nonporous surfaces.

Effective Cleaner

 Formulated with synthetic detergents to provide effective cleaning and disinfection in one step

Broad Spectrum Activity

 Provides broad spectrum efficacy of gram positive and gram negative micro-organisms and viruses, including Tb, HBV, HIV-1 (AIDS virus), MRSA, VRE, Vaccinia virus, Canine parvovirus and many more

Meets the OSHA Bloodborne Pathogen Standard

- ▶ Kills HBV and HIV-1 (AIDS Virus) in 1 minute
- ▶ Kills Tb in 10 minutes

Cost-Effective

 Highly concentrated phenolic forumla cleans at 1/2 oz. per gallon (1:256)

Designed For

- Health Care
- Education
- Lodging

Use Overview

Expose® II 256 is extremely versatile and can be applied with a mop, sponge, or cloth as well as soaking. Use on hard, nonporous surfaces such as floors, walls, painted surfaces, exterior bowl surfaces, empty basins, showers, conductive flooring and lavatory fixtures.

- Pre-clean if heavily soiled.
- ▶ Thoroughly wet surfaces with the use solution for 10 minutes.
- Wipe dry.
- ▶ Food contact surfaces must be rinsed with potable water.
- Rinsing is not necessary on floor surfaces unless floors are to be waxed or polished.



Product Specifications

Description	
EPA Reg. No.	70627-6
Color/Form	Transparent, purple liquid
Flash Point	127° F (53° C)
рН	12.75 (Concentrate) 9.9 (Use Dilution)
Scent	Citrus phenolic
Solubility	Complete
Specific Gravity	1.11

Available Items

Product Code	Description/Package Size	Dilution
05697	4 x 64 oz. / 1.89 L Solutions Center® Bottles	1:256
05699	2 x 2.5 L / 84.5 oz. J-Fill® Bottles - Concentrate	1:256
5271301	2 x 1.5 gallon / 5.67 L Command Center® Units	1:256

Safety Reminder

Please make sure your employees read and understand the product label and Material Safety Data Sheet before using this product. The label contains directions for use, and both the label and MSDS contain hazard warnings, precautionary statements and first aid procedures. MSDS are available on-line at www.diversey.com or by calling 888 352 2249.

Hazard Rating

HMIS	Concentrate	NFPA
3	Health	3
1	Flammability	1
0	Reactivity	0
HMIS	Use Dilution	NFPA
HMIS 0	Use Dilution Health	NFPA 0
0	Health	0

 $^{4 \! = \! \}mathsf{Very\,High}; 3 \! = \! \mathsf{High}; 2 \! = \! \mathsf{Moderate}; 1 \! = \! \mathsf{Slight}; 0 \! = \! \mathsf{Insignificant}.$

