

High-performance acidic rinse aid

# **B 200 S**

### Concentrated, all-purpose rinse aid for all water areas

### **AREA OF APPLICATION:**

- Suitable for all commercial glass- and dishwashing machines.
- Suitable for all kind of dishwashing items made of glass, porcelaine, ceramic, plastic, stainless steel, aluminium and silver.
- Suitable for all water areas, especially for hard water.

For perfect cleaning results, we recommend using the Winterhalter system with an appropriate warewasher, water treatment and rinse aids.



## **PRODUCT ADVANTAGES:**

- Improved excellent dish wetting
- Spotless drying
- Brillant shine
- Foam supressing
- Assures beer head stability

### **DOSAGE:**

Dispensed by an electronic feeder, depending on the type of the dishes and the water quality:

Water quality	Dosage in ml/l	°dH	[µS]	ppm CaCO <sub>3</sub>
Osmose	0.1-0.4	0	0	0
Soft	0.1-0.4	< 8	0-240	< 150
Medium	0.1-0.4	< 14	240-420	< 250
Hard	0.1-0.4	> 14	> 420	> 250

### **INGREDIENTS:**

Citric acid 1 - 10%, Sodium cumene sulphonate 5 - 10%, Surfactants 10 - 20%









- The special composition ensures optimal drying performance and is gentle on delicate surfaces.
- All Winterhalter chemicals are non-toxic, non-carcinogenic and are free of NTA and EDTA.
- Certified according DIN ISO 9001, 14001 and 18001.
- Winterhalter chemicals comply with DIN 10 510 to 10 512 and DIN 10 522.
- Original German Formula manufactured in Australia.

# **Technical data sheet**



High-performance acidic rinse aid

# **B 200 S**

#### **DELIVERY SIZES:**

51	PE bottle
15 l	PE bottle

### **TECHNICAL DATA:**

Colour	colourless	
Odour	product-specific	
pH value	approx. 2	
Shelf life	12 months	
Storage conditions	cool, dark, frost-free to max. 25 °C	
Density	approx. 1,03 g/cm³	

### **SAFETY NOTES:**

Causes serious eye irritation.

Wash skin thoroughly after handling.

Wear eye protection/face protection.

IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

If eye irritation persists: Get medical advice/attention

Dispose of contents/container in accordance with state regulations

### **DISPOSAL OF EMPTY PACKAGING:**

- Completely emptied packaging is recyclable.
- Information on disposal of product residues can be found in the safety data sheet.

#### **IMPORTANT:**

- Product is not intended for the general public. For commercial use only!
- Storage and transport permissible only in original packaging in upright position. Do not expose to direct sunlight. Protect from freezing.
- B 200 S can be used in connection with all customary detergents for commercial glass- and dishwashing machines and is suitable for the food sector.
- Containers, pipes and dosing equipment should be rinsed with fresh water before chaning products.
- A filling funnel (60 005 163) for safe and exact filling of the built-in detergent container in Winterhalter-UC-models is available. To avoid confusion, B 200 S may only be filled in containers marked rinse aid.
- Never mix with other products and do not refill in other containers, bottles etc.!
- Colour variations in the product are caused by raw materials and storage and do not affect quality.
- To ensure that your dishwasher functions durably and reliably, all filters should be cleaned at end of operation after the self-cleaning programme has ended. Leave the machine open slightly so the interior can dry and in order to build up corrosion protection.
- You will find this product's safety data sheet and technical data sheet on our homepage at www.winterhalter.com.au