

## Release Notes for Unified ITV2 (DSC PowerSeries Neo) Intrusion Integration v4.8.57.0

---

Document Revision B0

December 2016

This document provides important information about the installation and features of the Unified victor ITV2 Intrusion Integration. Read this document before you install the product.

### **Product:** Unified ITV2 Intrusion Integration

- Integration Software Version: 4.8.57.0
  - Release Version: 4.9
- Note:** This version is also compatible with victor Unified client versions: 4.6, 4.7, 4.7.1, 4.8, 4.8SP1, and 4.8.1.

## 1. Overview

---

The victor ITV2 Intrusion Integration provides an advanced integration with the DSC PowerSeries Neo Panels. It enables users of victor Unified Client to monitor and configure ITV2 devices, hardware, and alarms from the victor environment.

## 2. Features

---

ITV2 Intrusion Integration supports the following features:

- DSC Neo Panels.
- Supports synchronization of the following objects from the Panel and to the Panel:
  - Partition
  - Zones
  - Output
  - Virtual Zones
- Supports the following actions to control the ITV2 Intrusion Integration objects from victor:
  - Partition: Arm or Disarm
  - Zone: Bypass or Reset
  - Output: Activate or Deactivate
- Firmware download from the panel.
- victor Alarm Filtering, Virtual Keypad, Roles, and Object Association.
- victor Client-side Event Management.
- Devices on victor Maps and Health Dashboard.
- 150 panels in a single CrossFire Server.

## 3. Qualified Hardware and Firmware

---

ITV2 Intrusion Integration has the same hardware, and disk space requirements as the victor Application Server. If the target computer meets victor Application Server requirements, then it meets ITV2 Integration requirements.

Supported ITV2 Intrusion Integration Panels are:

- DSC Neo Panel

The ITV2 Intrusion Integration requires the following firmware:

- Keypad: v01.10.01.51/v01.11.01.13/v1.20.01.29
- Communicator TL280/TL280R/TL2803G: v04.11.04.31, v5.00.04.27, v05.20.01.29
- DSC NEO Panel UA621 REV03: v01.12.01.13, v01.14.01.10, v1.20.01.31, v1.21.01.01, 01.30.01.08

## 4. Software Requirements

The ITV2 Intrusion Integration requires the following software:

- C-CURE 9000 Standalone: v2.4, 2.41, 2.42, 2.5, and 2.51
- victor Application Server: v4.6, 4.7, 4.7.1, 4.8, 4.8SP1, 4.8.1 and 4.9
- victor unified client: v4.6, 4.7, 4.7.1, 4.8, 4.8SP1, 4.8.1 and 4.9

## 5. Contents of the Installation Driver

The following table lists the contents of the ITV2 Intrusion Integration installation package:

File	Description
ITV2_Integration.exe	Installation program for the ITV2 Integration software
8200-1147-94 C0_4.8.1_victor_ITV2_DSCTPowerSeriesNeoPanel_Integration_UM.pdf	victor ITV2 DSC PowerSeries Neo Panel Integration User Guide
8200-1147-1001 B0_4.9_victor_ITV2_DSCTPowerSeriesNeoPanel_Integration_RN.pdf	victor ITV2 DSC PowerSeries Neo Panel Intrusion Integration Release Notes

## 6. Supported Installation Types

The victor ITV2 Intrusion Integration supports the following installation types:

- Unified Standalone
- victor Standalone (victor 4.8.1 onwards)
- Unified Enterprise
- victor Enterprise (victor 4.8.1 onwards)

## 7. Pre-Installation

Before you install the ITV2 Intrusion Integration, ensure that your system meets the following criteria:

### On the victor Application Server:

1. You must have appropriate Windows permissions.
2. You must be a member in the local Administrators group, or have equivalent privileges.
3. You must install the victor Application Server with the following options:
  - ITV2 Intrusion Integration

### On the clients:

1. You must have appropriate Windows permissions.
2. You must be a member in the local Administrators group, or have equivalent privileges.
3. You must install the victor client.

## 8. Installation

**Note:** You must install the ITV2 Intrusion Integration in the same folder as victor. If the correct version of victor is not installed, a message is displayed prompting you to install the correct version.

Follow the steps to install the ITV2 Intrusion Integration software on the server and remote clients:

1. Double-click the **ITV2\_IntrusionIntegration.exe** file. The Install Wizard begins. The ITV2 Intrusion Integration **Welcome** screen appears.
2. Click **Next** and follow the Install Wizard prompts.
3. On the **License Agreement**, select the **I accept the terms in the license agreement** check box and then click **Next**.
4. Click **Finish** to complete the installation.

**Note:** You cannot install the ITV2 Intrusion Integration server components on a victor Application Server MAS.

## 9. Post Installation

---

Follow the steps after installation:

1. Launch the **Server Configuration Application**:
  - a. On the taskbar, click the **Start** button and then click **All Programs**.
  - b. Click **Tyco**, right-click the **Server Configuration** and then click **Run as Administrator**. The **Server Configuration Application** page opens.
2. Start the **ITV2 Services**:
  - a. On the **Server Configuration Application** page, click to open the **Services** tab.
  - b. Ensure that both Crossfire Framework Service and Crossfire Server Component Framework Service are **running**.
  - c. In the **Extension Services** area, locate the **ITV2 Driver Service**. Select the **Enabled** check box and then click the **Start** button. The status of the ITV2 Driver Service changes to **Running**.
3. Launch the victor client:
  - a. On the taskbar, click the **Start** button and then click **All Programs**.
  - b. Click **victor**.

## 10. Upgrading the ITV2 Intrusion Integration

---

### Caution:

If you have made any changes in the configuration file - `ITV2Configuration.xml`, ensure that you back up the file before upgrading. The configuration file is located at `Tyco\CrossFire\ServerComponents`.

Follow the steps to upgrade the ITV2 Integration:

- Upgrade victor v4.8SP1 to victor v4.9, and then install the ITV2 Integration.
- Upgrade victor v4.8.1 to victor v4.9, and then install the ITV2 Integration.

## 11. Known Issues and Limitations

---

This section lists all the known issues and limitations in this release:

- User Defined Field (UDF) attribute of personnel is not applicable.
- All event groups for one panel can have only one journaling option in **Alarm Filter**.
- The ITV2 Integration is supported by victor, however in the **License Manager** ITV2 Integration is not listed in the victor tab.
- If the CrossFire server is installed with a remote SQL, you must manually change the **Connection Strings** under the **Database** tab on the **Server Configuration Application** window. For more information, see the troubleshooting section of the *C•CURE 9000 ITV2 Integration User Guide*.
- If you install the ITV2 Intrusion Integration on remote clients, the **Integration Setup** dialogue box appears and you may be prompted to select an **Installation Option** for Redundancy sever. Ignore this message and click **Next** to continue with installation.  
If you select the **Redundancy sever installation using supported third party redundancy** check box, provide the virtual server location, and then click **Next**; this selection is ignored and there is no functional impact.

## 12. End of Release Notes

---

The trademarks, logos, and service marks displayed on this document are registered in the United States [or other countries]. Any misuse of the trademarks is strictly prohibited and Tyco Security Products will aggressively enforce its intellectual property rights to the fullest extent of the law, including pursuit of criminal prosecution wherever necessary. All trademarks not owned by Tyco Security Products are the property of their respective owners, and are used with permission or allowed under applicable laws.

Product offerings and specifications are subject to change without notice. Actual products may vary from photos. Not all products include all features. Availability varies by region; contact your sales representative.

© 2016 Tyco Security Products.  
All rights reserved.