

NOTICE

- * Please make sure that you have all parts indicated and they are in good condition before you begin assembly of this item. Refer to part list and hardware list below for guidance.
- * This item should be assembled on a soft surface to prevent scratching the finish during assembly.
- * This item may require periodic tightening.
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com







PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with part contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 60 minutes.
- * Tools Required for Assembly (included): Allen Key

CARE AND MAINTENANCE


Adhesive felt pads should always be applied to areas of furniture which make direct contact with flooring, said application will prevent damage to the furniture and or surfaces on which the furniture lies. Objects placed on articles of furniture should rest on non abrasive material as to prevent damage to the wood finish. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish.

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	TOP PANEL		1X
B	LEFT LEG ASSEMBLY		1X
C	RIGHT LEG ASSEMBLY		1X
D	TOP RAIL		2X
E	LEG SUPPORT		2X
F	STRETCHER		1X













Model# DSK5010
Product Dimensions: 42"W x 20"D x 30"H





WEIGHT CAPACITY :
TOP : 100 LBS


WARNING: DO NOT OVER TORQUE
BOLTS/SCREWS

PIECE	DESCRIPTION	PICTURE	QTY
HW1	50 MM BOLT	M6x50mm 	8X
HW2	2" ROUND HEAD SCREW	M4x51mm 	2X
HW3	5/8" FLAT HEAD SCREW	M3x16mm 	8X
HW4	SPRING WASHER		8X
HW5	FLAT WASHER		8X
HW6	CAMBOLT	Ø8x32mm 	6X
HW7	CAMLOCK	Ø15x12mm 	6X
HW8	DOWEL	Ø8x28mm 	8X
HW9	SQUARE PLATE	50x50x3mm 	2X
HW10	ALLEN KEY		1X


PREPARATION

- * Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * Estimated Assembly Time: 60 minutes.
- * Tools Required for Assembly (included): Allen Key
- * If you are having difficulty, our friendly Customer Care team is always here to help. Please email customersupport@safavieh.com


	
<p>STEP 1 ATTACH CAMBOLTS (HW6) TO TOP PANEL (A).</p>	<p>STEP 2 ATTACH LEG SUPPORTS (E) TO LEFT LEG ASSEMBLY (B) AND RIGHT LEG ASSEMBLY (C) USING 50 MM BOLTS (HW1), SPRING WASHERS (HW4) AND FLAT WASHERS (HW5). TIGHTEN THE BOLTS USING ALLEN KEY (HW10).</p>




STEP 3 ATTACH TOP RAILS (D) TO TOP PANEL (A) USING CAMLOCKS (HW7).




STEP 4 ATTACH LEFT LEG ASSEMBLY (B) TO UNIT USING 50 MM BOLTS (HW1), SPRING WASHERS (HW4), FLAT WASHERS (HW5) AND DOWELS (HW8). TIGHTEN THE BOLTS USING ALLEN KEY (HW10).




STEP 5 ATTACH STRETCHER (F) TO UNIT USING 2" ROUND HEAD SCREW (HW2).



STEP 6 ATTACH RIGHT LEG ASSEMBLY (C) TO UNIT USING 50 MM BOLTS (HW1), SPRING WASHERS (HW4), FLAT WASHERS (HW5), DOWELS (HW8) AND 2" ROUND HEAD SCREW (HW2). TIGHTEN THE BOLTS USING ALLEN KEY (HW10).



STEP 7 ATTACH SQUARE PLATES (HW9) TO UNIT USING 5/8" FLAT HEAD SCREWS (HW3).



STEP 8 ADJUST THE ADJUSTER THAT HAS ALREADY BEEN ASSEMBLED TO THE LEGS TO STABILIZE YOUR UNIT.