

NOTICE

- *Please make sure that you have all the listed parts and check if they are in a good condition before you assemble this item. Please refer to parts and hardware listed below for guidance.
- *This item should be assembled on a soft surface to prevent any scratch on the finish when assembling the item.
- *This item may require a periodic tightening.
- *If you are having difficulty in assembling the item, our friendly Customer Care team is always ready to help. Please email customersupport@safavieh.com

PREPARATION

- *Before assembling the product, make sure you have all the complete parts. Compare the parts you have to the parts listed here.
- *If any part is missing or damaged, do not attempt to assemble the product.
- *The Estimated Time for Assembly: 10 minutes.
- *Tools Required for Assembly (included): Allen Key


CARE AND MAINTENANCE

Adhesive felt pads should always be applied to areas of furniture which make direct contact with flooring, said application will prevent damage to the furniture and or surfaces on which the furniture lies. Objects placed on articles of furniture should rest on non-abrasive material as to prevent damage to the wood finish. Objects whose composition consists of plastic and rubber are known to discolor and damage the wood surfaces on which they rest. Wipe up spills immediately and avoid common hazards such as hot dishes, harsh solvents, and abrasives. Cleaning should be done with a soft lint-free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from scratches and spills. How often you apply the wax depends on how much wear the furniture receives.



Item ID: DSK9400







Product Dimensions :27.55" X 22.36" X 75.98"



Weight Capacity: 40 lbs



Warning: DO NOT TORQUE BOLT


Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY	PIECE	DESCRIPTION	PICTURE	QUANTITY
A	SHELVES A		1x	HW1	BOLT M6X35MM		14x
B	SHELVES B		1x	HW2	DOWEL 08xX32MM		12x
C	DESK		1x	HW3	L PLATE		1x
D	LEFT UPPER LEG		1x	HW4	FISHER S6		1x
E	LEFT MIDDLE LEG		1x	HW5	ALLEN KEY		1x
F	LEFT LOWER LEG		1x	HW6	SREW 8 X1 1/4		1x
G	RIGHT UPPER LEG		1x	HW7	SCREW 8 x 5/8		1x
H	RIGHT MIDDLE LEG		1x	HW8	METAL PLATE		2x
I	RIGHT LOWER LEG		1x	HW9	SCREW 8 x 1/2		20x
J	TOP BAR		1x	HW10	LD PLATE		2x
				HW11	FLAT WASHER 6MM		18x
				HW12	BOLT M6 X 30		4x


PREPARATION

- * Before assembling the product, make sure you have all the complete parts. Compare the parts you have to the parts listed here.
- * If any part is missing or damaged, do not attempt to assemble the product.
- * The Estimated Time for Assembly: 10 minutes.
- * Tools Required for Assembly (included): Allen Key

	
STEP 1 : ATTACH THE LEFT LEG D/E/F USING BOLT (HW1),DOWEL (HW2), FLAT WASHER (HW10) & ALLEN KEY (HW5).REPEAT THE STEP FOR RIGHT LEG	STEP2 : ATTACH SHELVES A/B TO THE LEFT LEG USING BOLT (HW1),DOWEL (HW2), FLAT WASHER (HW11) ,& ALLEN KEY (HW5). AFTER THAT, ATTACH DESK USING LD METAL (HW10) , SCREW (HW9) ,BOLT (HW12) ,FLAT WASHER (HW11) ,& ALLEN KEY (HW5)





STEP3 : ATTACH SHELVES A/B TO THE RIGHT LEG USING BOLT (HW12),DOWEL (HW2), FLAT WASHER (HW11) ,& ALLEN KEY (HW5). AFTER THAT, ATTACH DESK USING LD METAL (HW8) , SCREW (HW9) ,BOLT (HW12) ,FLAT WASHER (HW11) ,& ALLEN KEY (HW5).






STEP4: INSERT SHELVES TOP BAR TO LEFT /RIGHT LEG. USING BOLT (HW1),DOWEL (HW2), FLAT WASHER (HW11) & ALLEN KEY (HW5) INSERT SCREW (HW9) ON LD PLAT

wall



STEP5 : ATTACH ANTI -TIP KIT TO HELP PREVENT
ETERAGE FROM TIPPING



STEP6 : THIS IS APPLICABLE ONLY TO A PAIR OF ETAGERE.
SKIP THIS INSTRUCTIONS IF YOU BUY A SINGLE ITEM .