MANUFACTURED FOR: MITSUBISHI ELECTRIC US, INC.

Wind Baffle WB-PA1

for use with:

PUY/Z-A12/A18 Outdoor Units

INSTALLATION MANUAL

FOR INSTALLER

For safe and correct use, please read this installation manual thoroughly before installing the advanced wind baffles.

English


⚠ WARNING! MOVING PARTS. INCORRECT HANDLING COULD LEAD TO DEATH OR INJURY!


IMPORTANT! Outdoor Unit should be installed with back coil surface facing a wall or oriented so the wind does NOT blow directly on to the back coil surface. Do not install this product where there is any obstacle at either side or above the outdoor unit. If the discharge air is obstructed the air may be short cycled.

STEPS:

- 1. Insert the 2 lower screws part way first.
- 2. Slide baffle into position using slots provided. Repeat with all baffles.
- 3. Install remaining screws and tighten all 4 screws securely.

ENSURE BAFFLE OUTLETS WILL NOT BE BLOCKED OR OBSTRUCTED!





This product is designed and intended for use in commercial and light-industrial environment.	
Please be sure to put the contact address/telephone number on this manual before handing it to the customer.	

 ${\bf Manufactured\ for\ MITSUBISHI\ ELECTRIC\ US,\ INC.}$

www.mitsubishielectric-usa.com Toll Free: 800-433-4822