



**INSTALLATION INSTRUCTIONS  
CAT-BACK EXHAUST SYSTEM  
2011 Dodge Avenger/Chrysler 200 V6  
Dual Rear Exit with 4.0" Pro-Series Tips  
PART NUMBER P5156013**

**Please take time to read and understand these installation instructions.**

MOPAR recommends that installation of this system be performed by a qualified service center or professional muffler installer who has the necessary equipment, tools and experienced personnel. However, if you decide to perform this install, the use of a hoist and an additional person will be required.

**CAUTION:** Never work on a hot exhaust system. Allow time for the vehicle to cool. Always wear eye protection when working under a vehicle.


Please confirm that all parts are present before beginning the factory exhaust system removal and MOPAR exhaust system installation.

**Bill of Materials:**

- 1- Tunnel Muffler Assembly (17JS2000)
- 2- Intermediate Pipe Assembly (17JS4004)
- 3- Driver Rear Muffler Assembly (17JS2002)
- 4- Passenger Rear Muffler Assembly (17JS2006)
- 5- Tip Assembly (17JS3000)
- 6- Hardware Kit (15CV7000)

**Recommended Tools:**

- Safety Glasses
- 15mm Socket
- 3/8" Ratchet
- Torque Wrench
- Grommet Pullers
- Soap & Water Solution





INSTALLATION INSTRUCTIONS  
CAT-BACK EXHAUST SYSTEM  
2011 Dodge Avenger/Chrysler 200 V6  
Dual Rear Exit with 4.0" Pro-Series Tips  
PART NUMBER P5156013

## Removal of Stock System:

1. Using a 15mm socket and ratchet, loosen the clamp near the front of the factory catback section (See Fig. A).
2. Begin to remove the hangers from the factory grommets. Grommet pullers and a soapy water solution will aid in this process. Also, use jackstands or the help of another person to support the exhaust system before removing all hangers to prevent injury and/or damage to the rear fascia (See Fig. B, C, D, E, F).
3. After removing all hangers from the factory grommets, pull the factory catback towards the rear of the car to remove from the factory headpipe (See Fig. G).
4. The removal of the stock exhaust is now complete (See Fig. H).



Fig. A




Fig. B



Fig. C



Fig. D



Fig. E



Fig. F



Fig. G



Fig. H



INSTALLATION INSTRUCTIONS  
CAT-BACK EXHAUST SYSTEM  
2011 Dodge Avenger/Chrysler 200 V6  
Dual Rear Exit with 4.0" Pro-Series Tips  
PART NUMBER P5156013

## Installation of MOPAR Exhaust System:

**NOTE:** Apply the anti-seize lubricant (supplied) to the threads ONLY of all the clamps and flange bolts. Failure to follow this procedure can cause nuts to seize on clamps and potentially destroy threads. After applying anti-seize lubricant, be sure to thoroughly clean hands as lubricant will tarnish stainless steel.

**NOTE:** Align all clamps so that the center of the clamp bolt is 90 degrees from the notch in the pipe (See clamp figure to the right).

All clamps should be tightened using a properly calibrated Torque Wrench. Using an air impact gun will damage the clamp and reduce its ability to effectively seal the joint. It may also cause the joint to separate thereby causing damage to your exhaust system and your vehicle.

1. Locate the MOPAR tunnel muffler assembly and a supplied 2.5" clamp (See Fig. I).
2. Slide the clamp over the expanded end of the tunnel muffler assembly oriented as shown. Then slide the expanded end of the tunnel muffler over the factory headpipe. Insert the tunnel muffler hanger into the factory grommet. Loosely snug the clamp at this time (See Fig. J, K, L).
3. Locate the MOPAR intermediate pipe and a supplied 2.5" clamp (See Fig. M).
4. Slide the clamp over the expanded side of the intermediate pipe and slide the expanded end of the intermediate pipe over the tunnel muffler outlet pipe. Use a jackstand to support the middle or rear of the intermediate pipe. The middle section of the intermediate pipe should be level and the outlets centered on the vehicle. Loosely snug the clamp at this time (See Fig. N, O).




Fig. I



Fig. J



Fig. K



Fig. L



Fig. M



Fig. N



Fig. O



INSTALLATION INSTRUCTIONS  
CAT-BACK EXHAUST SYSTEM  
2011 Dodge Avenger/Chrysler 200 V6  
Dual Rear Exit with 4.0" Pro-Series Tips  
PART NUMBER P5156013

5. Locate the MOPAR driver side rear muffler and a supplied 2.5" clamp. Slide the clamp over the expanded muffler inlet pipe and slide the muffler inlet onto the intermediate pipe outlet. Insert the hangers into the factory grommets. Support the muffler so that the muffler outlet pipe is level and loosely snug the clamp at this time (See Fig. P, Q, R, S).



**NOTE:**  
Drain  
hole in  
mufflers  
should  
face down.

6. Locate the MOPAR tip assembly and a supplied 2.5" clamp. Slide the clamp over the tip inlet pipe and slide the tip onto the muffler outlet pipe. Check tip alignment and loosely snug the clamp at this time (See Fig. T, U).



7. Repeat steps #6 and #7 for the passenger side.

Fig. P

8. Make any necessary and final adjustments for proper clearances and tip alignments. Starting from the front of the exhaust system, tighten all clamps to 45 ft-lbs (See Fig. V).



Fig. S



Fig. Q



Fig. R



Fig. T



Fig. U



Fig. V

**NOTE:** During cold weather start-ups, you may experience an exhaust sound that is deeper and louder in tone than usual. This is temporary and will diminish to normal levels once your engine has reached its normal operating temperature.

**NOTE:** Immediately following the installation of your MOPAR exhaust system, you may experience a trace of smoke after initial start-up. DO NOT be alarmed. The smoke is caused by the burning of a small amount of forming oil residue used in the manufacturing process.