


Media length calibration

The distance the media feeds through the machine depends on the drive drum radius and the media thickness:



In above diagram, the red colored media is thicker compared to the blue media. The red media will feed further than the blue media for the same amount of revolutions of the drive drum.

This can be compensated by performing a “media length calibration”. The calibration is stored per User Configuration. It is advised to change to another User Configuration before the calibration is performed. It is possible to change the name of the User Configuration to ease the memorization for which media the User Configuration was calibrated from Summa Cutter Control.

1. Power on the cutter
2. Load media in the machine for which you want to compensate for the media thickness.
3. Optionally change the user configuration, as the calibration is stored in the active user configuration (by default Configuration 1..8, name can be changed from Summa Cutter Control).
4. Verify knife settings (knife pressure and depth).



5. Click “Settings”
6. Click “More” to move to the next page.
7. Click “Length calibration”.


The cutter will cut a small cross in the lower left corner of the media.

Then a line is cut in the media movement direction. The length of the line depends on the length of the media, and will not exceed 900 mm. The longer the used media, the smaller the effect of the measurement error becomes.

A second cross is cut in the lower left corner of the media, on top of the first cross. Only one cross should be visible. In case two crosses are visible, then there may be a media feed issue, which should be cured before performing the media length calibration.

The cutter will then trim the media.

8. Weed the small triangles on the line-ends.
9. Measure the length of the line (excluding the triangles).



It is important to measure this length as accurate as possible to have the best compensation. Eventually use a magnifier. Do not use the start of the ruler as a reference.

10. Click “Measure lines” to change the displayed value to the measured length.
11. Click “Apply” to confirm.

Revised March 10, 2020