

Revision Number - 2

BLOWER PARTS

Callout	Name	Quantity	Description
	HOUSING-BLOWER Cat #: LB-28160AA Model/Part #: LB-28160AA	1	WELDED TO BLOWER DECK
19	PLATE-CUTOFF Cat #: 35A43 Model/Part #: LB-28346D	1	(FOR UNITS LESS ELEC HEAT)
19	PLATE-CUTOFF Cat #: 35A42 Model/Part #: LB-28347D	1	(FOR UNITS WITH ELEC HEAT)
20	RING-ORIFICE Cat #: 46A18 Model/Part #: LB-28040D	1	RING-ORIFICE
21	MOTOR-BLOWER Cat #: 32803 Model/Part #: 35A9001	1	"1/4HP,1075RPM,208-230/60/1"
22	BAND-MOTOR Cat #: 32866 Model/Part #: P-8-9501	1	BAND-MOTOR MTG
23	ARM-MOTOR MTG Cat #: 37A34 Model/Part #: 37A3401	3	ARM-MOTOR MTG
24	CAPACITOR Cat #: 53H02 Model/Part #: P-8-1379	1	"5MFD,370VAC"
25	WHEEL-BLOWER Cat #: 35A9101 Model/Part #: 35A9101	1	"1/2""BORE,10-5/8"" X 4-1/2""

CABINET PARTS

Callout	Name	Quantity	Description
	COVER-CONTROL BOX Cat #: LB-28095C Model/Part #: LB-28095C	1	AUXILIARY BOX(26-511 ONLY)
	BASE Cat #: 35C10 Model/Part #: LB-28103BA	1	BASE ASSY
	PIECE-FILLER Cat #: LB-28105CA Model/Part #: LB-28105CA	1	(FOR UNITS LESS ELEC HEAT)
	HINGE	1	HINGE

Callout	Name	Quantity	Description
	Cat #: LB-28153D Model/Part #: LB-28153D		
	PANEL Cat #: LB-28167BB Model/Part #: LB-28167BB	1	LEFT SIDE
1	PANEL Cat #: LB-28167BA Model/Part #: LB-28167BA	1	RIGHT SIDE
2	PANEL Cat #: LB-28145BA Model/Part #: LB-28145BA	1	BLOWER ACCESS
3	PANEL Cat #: LB-28142BA Model/Part #: LB-28142BA	1	REAR ACCESS
4	COVER-CONTROL BOX Cat #: LB-28148C Model/Part #: LB-28148C	1	COVER-CONTROL BOX
6	RACK-FILTER Cat #: 46A13 Model/Part #: LB-28013C	3	RACK-FLTR
7	COVER Cat #: 46A20 Model/Part #: LB-28108CA	1	ELEMENT
8	FILTER-AIR Cat #: 30345 Model/Part #: P-8-7816	1	"12" X 22" X 1", WASHABLE"

CONTROL PANEL PARTS

Callout	Name	Quantity	Description
	BRACKET Cat #: 46A14 Model/Part #: LB-28018D	1	BLO RELAY(EXCLUDING 26-511)
	STRAIN RELIEF Cat #: 85236 Model/Part #: P-8-4931	1	FITTING-STRAIN REL.
	FITTING Cat #: 59783 Model/Part #: P-8-4933	1	(FOR UNITS LESS ELEC HEAT)
	CLIP Cat #: P-8-5720 Model/Part #: P-8-5720	1	SECURING(FOR UNITS LESS ELEC HEAT)
	BLOCK-TERMINAL Cat #: 38674 Model/Part #: P-8-9957	1	(EXCLUDING 26-511)

Callout	Name	Quantity	Description
15	TRANSFORMER Cat #: 59539 Model/Part #: P-8-5744	1	"230V PRI,24V SEC,30VA,NO FUSE"
17	RELAY Cat #: 45A76 Model/Part #: P-8-11318	1	"BLOWER- DPDT,24V(FOR UNITS WITH ELEC HEA
17	RELAY Cat #: 38276 Model/Part #: P-8-8479	1	"BLOWER- SPDT,24V(FOR UNITS LESS ELEC HEA

COOLING PARTS

Callout	Name	Quantity	Description
	PAN-DRAIN Cat #: 46A21 Model/Part #: LB-28125BA	1	VERTICAL
	PAN-DRAIN Cat #: 46A22 Model/Part #: LB-28128BA	1	HORIZONTAL
10	COIL-INDOOR Cat #: 42A93 Model/Part #: LB-28132C	1	L/MANIFOLD
11	DISTRIBUTOR Cat #: 40A76 Model/Part #: P-8-10368	1	L/TUBES
12	ADAPTER Cat #: 59351 Model/Part #: P-8-2510	1	ADAPTOR
13	ADAPTER Cat #: 59352 Model/Part #: P-8-2690	1	ADAPTER-BRASS

ELECTRIC HEATING PARTS

Callout	Name	Quantity	Description
	WIRE-ELEMENT Cat #: 82A41 Model/Part #: 37A4001	1	"2.5KW,240V(FOOTNOTE 5)"
	WIRE-ELEMENT Cat #: 82A53 Model/Part #: 37A4101	3	"5KW,240V"

Callout	Name	Quantity	Description
26	ELEMENT-ELEC Cat #: 82A53 Model/Part #: LB-28180A	1	CB11-26-171
26	ELEMENT-ELEC Cat #: LB-28181A Model/Part #: LB-28181A	1	CB11-26-261
26	ELEMENT-ELEC Cat #: 47A37 Model/Part #: LB-28182A	1	CB11-26-341
26	ELEMENT-ELEC Cat #: 47A38 Model/Part #: LB-28183A	1	CB11-21-511
27	CONTROL-LIMIT Cat #: 38A73 Model/Part #: 38A7301	3	"SPST,OUT 160,IN 125"
28	FUSE THERMAL Cat #: 87107 Model/Part #: P-8-10422	3	FUSE-THERMAL
29	RELAY Cat #: 35A2901 Model/Part #: 35A2901	1	"HEAT- DPST,24V(FOOTNOTE 2)"
29	RELAY-DELAY Cat #: 35A30 Model/Part #: 35A3001	1	"HEAT #2- SPST,24V(FOOTNOTE 4)"
29	RELAY Cat #: 35A3101 Model/Part #: 35A3101	1	"HEAT #1- DPST,24V(FOOTNOTE 3)"
30	RELAY-DELAY Cat #: 35A30 Model/Part #: 35A3001	1	"HEAT #2- SPST,24V(FOOTNOTE 4)"
31	BLOCK-TERMINAL Cat #: 66520 Model/Part #: P-8-163	1	STRIP-TERMINAL
32	BLOCK-FUSE Cat #: 37A32 Model/Part #: 37A3201	1	BASE-FUSE
33	FUSE Cat #: 57771 Model/Part #: P-8-418	2	"FRN TYPE,30AMP,250V"
33	FUSE Cat #: 37916 Model/Part #: P-8-5852	2	"FRN TYPE,60AMP,250V"

Note:

Note1: THIS PART MUST BE PLACED LAST IN SEQUENCE, FARTHEST DOWNSTREAM FROM BLOWER. Note2: WHEN 35A3001 (ROBERTSHAW) IS N.A., ORDER LB-53619CC RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 69C9901 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note3: WHEN 35A3101 (ROBERTSHAW) IS N.A., ORDER LB-53619CC RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 69C9901 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note4: WHEN 35A2901 (ROBERTSHAW) IS N.A., ORDER LB-53619CB RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 58C9901 (THERMODISC) RELAY IS THE CORRECT REPAIR PART. Note5: WHEN 35A3001 (ROBERTSHAW) IS N.A., ORDER LB-53619CA RELAY REPLACEMENT KIT. ONCE THE REPLACEMENT KIT HAS BEEN APPLIED, 58C9701 (THERMODISC) RELAY IS THE CORRECT REPAIR PART.