



2" WHEEL SPACER KIT INSTRUCTIONS FOR 6-5.5" & 8-6.5" WHEEL PATTERNS

Thank you for choosing Rough Country for all your suspension needs.

Professional knowledge of disassemble/reassembly procedures as well as post installation checks must be known. Attempts to install these wheel spacers without this knowledge and expertise may jeopardize the integrity and/or operating safety of the vehicle. Please read instructions before beginning installation. Also please review tools needed list and make sure you have needed tools.

Important Note: Spacers must be periodically checked to ensure tightness.

Kit Contents:

Part #1101 2-2+Wheel Spacers (6 LUG)

Part #1095 2-2+Wheel Spacers (8LUG)

Tools Needed:

Torque Wrench

Jack Stands

Socket wrench

Floor Jack

Sockets

INSTALLATION INSTRUCTIONS

1. Chock the tires and jack up the vehicle.
2. Remove the lug nuts and remove the tire and wheel. If retaining clips are present they must be removed for the spacer to sit flat on the rotor surface. **Note: Failure to remove the factory retaining clips on the wheel studs could result in a wheel /tire vibration.**
3. Install the wheel spacers as shown with the supplied lug nuts. **See Photo 1.** Tighten to manufacturer specifications using a 19mm wrench. **DO NOT EXCEED MANUFACTURER SPECIFICATIONS.**
4. Reinstall the tires/wheels on the wheel spacers.
5. Tighten the lug nuts holding the wheels and tires to factory specifications.



Photo 1

1101 2" THICK 6-5.5" PATTERN WHEEL SPACER



#1095/1099 2" THICK 8-6.5" PATTERN WHEEL SPACER



By purchasing any item sold by Rough Country, LLC, the buyer expressly warrants that he/she is in compliance with all applicable Federal, State, and Local laws and regulations regarding the purchase, ownership, and use of the item. It shall be the buyers responsibility to comply with all Federal, State and Local laws governing the sales of any items listed, illustrated or sold. The buyer expressly agrees to indemnify and hold harmless Rough Country, LLC for all claims resulting directly or indirectly from the purchase, ownership, or use of the items.

Post Installation

- **Spacers must be re-torqued periodically. Visually inspect components and re torque fasteners during routine vehicle service.**